



RTS SYSTEMS

PROFESSIONAL INTERCOMMUNICATIONS

PROFESSIONAL AUDIO PRODUCTS

1100 WEST CHESTNUT STREET

BURBANK, CALIFORNIA 91506

PHONE 818/843-7022

TELEX 194855

Series 800 Intercom

MODEL 802

Master Station

NOTICE:

Warning: This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference."

Specifications For RS232 Operation

The following criteria are established as requirements for the RS232 communications option for the RTS Systems Model 802.

1. Operate and interrogate all front panel buttons.
2. Inhibit operation of front panel buttons.
3. Determine Status of all DIP switches (byte wide).
4. Read and modify all programmable (RAM) memory.
5. Operate all relays, talk/listen gates, key lines independently of button positions.
6. Initiate a warm or cold start.
7. Always send out a code upon operator initiation of warm or cold start.
8. On command, send out a code upon operator initiation of any function, front panel or DIP switch change.
9. RS232 software should never cause the 802 to hang or lock up.
10. Host computer should have the ability to write and execute machine code in RAM for diagnostic or other purposes.

RS232 Language Implementation

For RS232 communications, the buttons are numbered from 1 to 48.

The physical front panel buttons are numbered 1 to 32. Certain connections to the rear panel are numbered 33 to 48.

<u>Code</u>	<u>Definition</u>
1-12	Top row of front panel buttons.
13-24	Second row of front panel buttons.
25-32	Function buttons, front panel, bottom row.
33	External camera iso input.
34	External global reset tally.
35	External mic.
37-48	Call light inputs (from phase lock loops).

By treating the external contacts as if they were front panel buttons, the external host computer can turn them on or off, inhibit the function completely (in either the on or off position), assign a relay to the function, force a chime signal, et cetera.

ADDENDUM TO TECHNICAL DATA PACKAGE
Model 802 Intercom Station

Command Structure

All commands will be initiated by a letter, followed by a numeric modifier, followed by an operator, followed by a terminating carriage return. The command letter indicates the major functions such as **BUTTON**, **KEY**, **RELAY**, **MEMORY**, et cetera. The numeric modifier usually refers to which button, or relay or memory is associated with that particular command. The operator tells the 802 whether to turn something on (+) or off () or to inquire about its present state (?).

Some commands have no modifiers or operators such as **WARM START** or **COLD START** or **VERSION**.

All commands must be terminated in a carriage return before the 802 will act on them.

Command lines must be limited to 128 characters in length. (Only the load memory command has the capability of exceeding this limit.)

Error Handling

The 802 cannot stop when it encounters a confusing a command, it will simply ignore the entire command. Specific errors include a command letter not in its command table, a numeric modifier that is out of range (for example, relay 12), and unrecognizable operator, et cetera. Upon detection of an error, the interpreter will normally ignore the remainder of a command.

The 802 will send out the letter E along with a 2 digit code indicating where the command interpreter was confused:

Code	Definition
E00	Syntax error.
E01	Output buffer overflow.
E03	Unrecognizable command modifier (+, -, or ? expected).
E04	Number out of range (for example, illegal button number).
E10	RS232 framing or parity error.
E20	RS422 framing or parity error.

ADDENDUM TO TECHNICAL DATA PACKAGE
Model 802 Intercom Station

Examples of Commands and Responses

The following examples of host computer commands use button 12, relay 5, address 0100 (hex) as examples.

<u>Function</u>	<u>Host Command</u>	<u>802 Response</u>
Turn Button On:	B12+	None
Turn Button Off:	B12-	None
Test Button Status:	B12?	+ or -
Inhibit Button's Use By Operator (function may be on or off)	I12+	None
Allow Button's Use By Operator:	I12-	None
Test If Inhibited:	I12?	+ or -
Assign Relay To Button:	B12R5+	None
Remove Relay Assignment:	B12R5-	None
Test Which Relays Assigned To Which Button:	B12R?	123456 (or any combination)
Turn On Relay:	R5+	None
Turn Off Relay:	R5-	None
Test Relay Status:	R5?	+ or -
Turn On a Gate:	G12+	None
Turn Off a Gate:	G12-	None
Test Gate Status:	G12?	+ or -
Turn On Key	K12+	None
Turn Off Key	K12-	None
Test Key Status	K12?	+ or -
Load Memory	M0100, 04, 0D,	None
Dump Memory	D0100	0100: 04 0D 0A 00
Dump Additional Memory	D	0110: BC 9A 88 C3
Enter Setup Mode	S+	None
Exit Setup Mode	S-	None
Execute at Address	X0100	None

ADDENDUM TO TECHNICAL DATA PACKAGE
Model 802 Intercom Station

Eavesdrop Mode

The eavesdrop mode sends to the host computer an indication of whether the operator has turned a function on or off. It reflects the status of the panel light under the button.

<u>Function</u>	<u>Host Command</u>	<u>802 Response</u>
Turn Eavesdrop Mode On:	E+	None until a button pushed by the operator turns a function on (B12+) or off (B12-). B12- (if 12 turned off)
Turn Eavesdrop Mode Off:	E-	None
Test Eavesdrop Mode:	E?	+ or -
Warm Start:	C	C
Version Number:	V	RTS021284


Possible problems with relay command: The relays are updated every time a button is pushed or released. This means that if the host computer turns on a relay, it may be turned off the next time the operator pushes any button.

Keys and gates have a similar problem, but will only be affected if the operator pushed the button associated with that particular key or gate.

Rev. B Changes: Page 3, Host Command, Lines 4, 5 6,: Change 112 to I12.

All product information and specifications subject to change without notice.

MODEL 802 MASTER STATION,
 TECHNICAL DATA PACKAGE, TDP 3510
 OCTOBER 1986 / SECOND EDITION/Written & Edited by Stan Hubler
 RTS SYSTEMS, INC.
 1100 W. CHESTNUT ST., BURBANK, CALIFORNIA 91506, U.S.A.



MODEL 802 MASTER STATION

PROPRIETARY NOTICE

The information and design disclosed herein were originated by, and are the property of, RTS Systems, Inc.. RTS Systems reserves all patent, proprietary design, manufacturing, reproduction, use and sales rights thereto, and to any article disclosed therein, except to the extent rights are expressly granted to others.

Copyright 1986 by RTS Systems. Reproduction in whole or in part without prior written permission from RTS Systems is prohibited.

PATENT NOTICE

The Model 802 contains and uses a design embodied in United States Patent No. 4,358,644: a "BILATERAL CURRENT SOURCE FOR A MULTI-TERMINAL INTERCOM". This design employs a bilateral current source operated as a two-wire to four-wire converter.

NOTE: DETAILED INFORMATION CONCERNING THEORY OF OPERATION, MAINTENANCE, SPARE PARTS AND SYSTEM INTERCONNECTION IS AVAILABLE IN: "THE MODEL 802 MASTER STATION TECHNICAL MANUAL", WHICH MAY BE OBTAINED FROM EITHER AN RTS SYSTEMS' DEALER OR DIRECTLY FROM THE FACTORY.

TABLE OF CONTENTS	PAGE
TABLE OF CONTENTS	2
WARRANTY	4
PROCEDURE FOR RETURNS	5
SHIPPING TO MANUFACTURER FOR REPAIR OR ADJUSTMENT	5
 SECTION 1: DESCRIPTION, OPERATION, AND SPECIFICATIONS	 7
MODEL 802 DESCRIPTION/OPERATION	7
FRONT PANEL: DESCRIPTION AND OPERATION	11
ADJUSTMENT BOARD: DESCRIPTION AND OPERATION	13
REAR PANEL: DESCRIPTION AND OPERATION	14
INTERFACING TO OTHER EQUIPMENT	15
SPECIFICATIONS	16
 SECTION 2: INSTALLATION	 17
MECHANICAL INSTALLATION	17
ELECTRICAL INSTALLATION/POWER	17
ELECTRICAL INSTALLATION/GROUNDING	18
ELECTRICAL INSTALLATION/SIGNALS/GENERAL	18
ELECTRICAL INSTALLATION/SIGNALS/FEATURES	25
ELECTRICAL INSTALLATION/HEADSETS	28
--HEADSET REQUIREMENTS	28
--HEADSET CONNECTIONS	28
ELECTRICAL INSTALLATION/SIGNALS/MODEL 802 TO MODEL 801/860	29
ELECTRICAL INSTALLATION/SIGNALS/MODEL 802/TELEPHONE	33
ELECTRICAL INSTALLATION/SIGNALS/MODEL 802/SERIES 4000 IFB	36
ELECTRICAL INSTALLATION/SIGNALS/MODEL 802/SERIES 1000 SQUAWK	42
ELECTRICAL INSTALLATION/SIGNALS/MODEL 802/VIDEO ISO	46
 SECTION 3: INSTRUCTIONS FOR PROGRAMMING THE MODEL 802	 51

TABLE OF FIGURES	PAGE
FIGURE 1-1, MODEL 802 BLOCK DIAGRAM	6, 8
FIGURE 1-2, MODEL 802 FRONT PANEL	10
FIGURE 1-3, MODEL 802 ADJUSTMENT BOARD	12
 FIGURE 2-1, MODEL 802 POWER SUPPLY CONNECTIONS	 17
FIGURE 2-2, ALL MASTER STATION SYSTEM	19
FIGURE 2-3, TERMINATOR PLUG	19
FIGURE 2-4, MASTER STATION SYSTEM AND MODEL 862	20
FIGURE 2-5, TERMINATOR PLUG FOR MODEL 862	20
FIGURE 2-6, CHANNEL 12 TERMINATION	21
FIGURE 2-7, MODEL 802/TW INTERCOM SYSTEM BLOCK DIAGRAM	22
TABLE 2-1, CONNECTOR CODE TABLE	23
FIGURE 2-8, DARLINGTON KEY OUTPUT	24
FIGURE 2-9, KEY OUTPUT APPLICATION	24
FIGURE 2-10, MODEL 802 REAR PANEL CONNECTIONS	26

TABLE OF FIGURES (CONTINUED)

PAGE

FIGURE 2-11, CASE 1: SIX CHANNEL 802 TO SIX CHANNEL 801	30
FIGURE 2-12, CASE 1: FRONT PANEL LEGEND	30
FIGURE 2-13, CASE 2: TWELVE CHANNEL 802 TO SIX CHANNEL 801	31
FIGURE 2-14, CASE 2: FRONT PANEL BUTTON LEGEND	32
FIGURE 2-15, USING A MODEL 801 IN AN MODEL 802 SYSTEM.	32
FIGURE 2-16, METHOD 1: MODEL 802 TO TELEPHONE CONNECTION	34
FIGURE 2-17, METHOD 2: MODEL 802 TO TELEPHONE CONNECTION	34
FIGURE 2-18, METHOD 3: MODEL 802 TO TELEPHONE CONNECTION	35
FIGURE 2-19, METHOD 4: MODEL 802 TO TELEPHONE CONNECTION	35
FIGURE 2-20A METHOD A: MODEL 802 TO IFB CONNECTION (4 IFB'S)	37
FIGURE 2-20B METHOD A: MODEL 802 TO IFB CONNECTION (8 IFB'S)	38
FIGURE 2-21, METHOD B: MODEL 802 TO IFB CONNECTION (4 IFB'S)	39
FIGURE 2-22, METHOD B: MODEL 802 TO IFB CONNECTION (8 IFB'S)	40
FIGURE 2-23, FRONT PANEL BUTTON ARRANGEMENT FOR 4 IFB'S.	41
FIGURE 2-24, FRONT PANEL BUTTON ARRANGEMENT FOR 8 IFB'S.	41
FIGURE 2-25 FRONT PANEL BUTTON ARRANGEMENT FOR 6 SQUAWKS	43
FIGURE 2-26, FRONT PANEL BUTTON ARRANGEMENT FOR 10 SQUAWKS	43
FIGURE 2-27, METHOD A: MODEL 802 TO SQUAWK CONNECTION	44
FIGURE 2-28, METHOD B: MODEL 802 TO SQUAWK CONNECTION	45
FIGURE 2-29, FRONT PANEL BUTTON ARRANGEMENT FOR ISO(METHOD B)	46
FIGURE 2-30, METHOD A: MODEL 802 TO ISO CONNECTION	47
FIGURE 2-31, METHOD B: MODEL 802 TO ISO CONNECTION	48
FIGURE 2-32, MOTHERBOARD DIP SWITCH ASSEMBLY	49
 FIGURE 3-1, MODEL 802 FRONT PANEL PROGRAMMING BUTTONS	 50

DIAGRAMS; DRAWING NUMBER

PAGE

ASSEMBLY, MODEL 802, ADJUSTMENT BOARD; AS 3000-7.	57
ASSEMBLY, MODEL 802, CALL LIGHT OPTION BOARD; AS 3000-18	59
ASSEMBLY, MODEL 802, CPU BOARD; AS 3000-5	61
ASSEMBLY, MODEL 802, FOUR WIRE OPTION BOARD; AS 3000-6.	63
ASSEMBLY, MODEL 802, IFB OPTION BOARD; AS 3000-2	65
ASSEMBLY, MODEL 802, MOTHERBOARD; AS 3000-1	67
ASSEMBLY, MODEL 802, PIO BOARD; AS 3000-4	69
ASSEMBLY, MODEL 802, TALK/SQUAWK OPTION BOARD; AS 3000-3	71
ASSEMBLY, MODEL 802, SWITCH BOARD; AS 3000-9.	73
SCHEMATIC, MODEL 802, SD 3000	75

RTS SYSTEMS' LIMITED WARRANTY

The products of RTS Systems, Inc., a California corporation, are warranted to be free from defects in materials and workmanship for a period of one year from the date of sale.

RTS Systems' sole obligation during the warranty period is to provide, without charge, parts and labor necessary to remedy covered defects appearing in products returned prepaid to RTS Systems, 1100 W. Chestnut Street, Burbank, California, 91506, U.S.A.. This warranty does not cover any defect, malfunction or failure caused beyond the control of RTS Systems, including unreasonable or negligent operation, abuse, accident, failure to follow instructions in the Owner's Manual, defective or improper associated equipment, attempts at modification and repair not authorized by RTS Systems, and shipping damage. Products with their serial numbers removed or effaced are not covered by this warranty.

To obtain warranty service, follow the procedures entitled "PROCEDURE FOR RETURNS" and "SHIPPING TO MANUFACTURER FOR REPAIR OR ADJUSTMENT" listed below.

This warranty is the sole and exclusive express warranty given with respect to RTS Systems products. It is the responsibility of the user to determine before purchase that this product is suitable for the user's intended purpose.

ANY AND ALL IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY ARE LIMITED TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY.

NEITHER RTS SYSTEMS NOR THE DEALER WHO SELLS RTS SYSTEMS' PRODUCTS IS LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND.

RETURN SHIPPING INSTRUCTIONS

PROCEDURE FOR RETURNS

If repair is necessary, contact the dealer where this unit was purchased.

If repair through the dealer is not possible, contact the RTS Systems Order Service Department by telephone, as directed below, to obtain a Return Authorization Number.

DO NOT RETURN ANY EQUIPMENT DIRECTLY TO THE FACTORY WITHOUT FIRST OBTAINING A RETURN AUTHORIZATION NUMBER.

Be prepared to provide your company's name, address, phone number, a person to contact regarding the repair, the type and quantity of equipment, a description of the defect, and the serial number(s).

Questions regarding returns for repair should be directed to:

Customer Service Department
RTS Systems, Inc.
1100 W. Chestnut St.
Burbank, CA 91506

TELEPHONE: (818) 840-7311
TELEX: 194855
TWX: 910-498-4987
TELEFAX: (818) 846-5197

SHIPPING TO MANUFACTURER FOR REPAIR OR ADJUSTMENT

All shipments of RTS Systems, Inc. equipment should be made via United Parcel Service or the best available shipper, prepaid. The equipment should be shipped in the original packing carton; if that is not available, use any suitable container that is rigid and of adequate size. If a substitute container is used, the equipment should be wrapped in paper and surrounded with at least four inches of excelsior or similar shock-absorbing material. All shipments should be directed to the attention of the Order Service Department and must include the Return Authorization Number.

Upon completion of repairs equipment will be returned via United Parcel Service or specified shipper, collect.




FIGURE 1-1
 MODEL 802 BLOCK DIAGRAM
 October 15, 1986/ Page 6

SECTION 1: DESCRIPTION, OPERATION, AND SPECIFICATIONS

MODEL 802 DESCRIPTION/OPERATION

The Model 802 Master Station, is a microprocessor-assisted communications control center. Each Master Station is a "stand alone" unit, that can be used either singly or in multiples. A Master Station can connect to, access, and control a variety of different communications systems, including the RTS Systems: 1) "TW" intercom system, 2) IFB system, and 3) station isolate system.

In addition, each Master Station functions as a multi-channel communications unit, used either:

- (1) as a unit along a multi-unit conference bus or
- (2) as a unit in a multi-unit point-to-point matrix-style communications system or,
- (3) as a combination of (1) and (2) above.

The Master Station Block Diagram, Figure 1-1, shows the Master Station functional components, input/output connections, and controls.

Functional Components:

- 1) Two microphone preamplifiers each with a limiter
- 2) A panel microphone/headset microphone select electronic switch
- 3) A microphone on/off electronic switch
- 4) "Talk circuitry" consisting of:
 - Talk channel select electronic switches
 - "Bilateral current source" line drivers
 - Listen balance controls
 - Individual listen level controls
 - Individual listen electronic switches

(Continued)




FIGURE 1-1
MODEL 802 BLOCK DIAGRAM
 802/2nd Ed./October 15, 1986/Page 8

Functional Components: (Continued)

- 5) A 16-source listen assign switch matrix
- 6) A "master" listen volume control
- 7) A two channel (stereo) headphone amplifier
- 8) A speaker on/off electronic switch
- 9) A speaker "dim" electronic switch
- 10) A speaker amplifier
- 11) An internal speaker disable switch
- 12) A microprocessor control system, which includes:

Front panel button inputs (32)

Talk and listen electronic switch control outputs

Microphone and speaker electronic switch control outputs

Relay control outputs (6)

Key outputs (12)

Headset present sense input

User programmed memory with battery backup

Adjustment board programming input switches (8)

Mother board programming input switches (8)

Additional outputs to control some options

"Reset" switch (tells microprocessor to reconfigure,
using adjustment and mother board programming inputs)

Factory installed "firmware" (operating system for
microprocessor)




FIGURE 1-2
MODEL 802 FRONT PANEL

FRONT PANEL: DESCRIPTION AND OPERATION (See Figure 1-2)

The front panel contains 24 selector buttons {4}, eight operation buttons {5}, master {11} and auxiliary {12} volume controls, loudspeaker {2}, gooseneck microphone {3}, dynamic {14} and carbon {13} microphone headset connectors, and access to the adjustment board {1}.

The selection {4} and operation {5} buttons have different functions when the Model 802 is switched from the standard, "operating" mode to the "programming" mode. Legends under each button show its "programming" function. See Section 3 for programming instructions.

In the basic Model 802, the first twelve selection buttons {4A} activate the talk circuits (top buttons), and listen circuits (bottom buttons) of intercom channels 1 through 6. The remaining twelve selection buttons {4B} become operational with the addition of options. Normally, the eight operation buttons {5} work as follows: PRESET 1 through PRESET 4 {6} can be user-programmed to activate, by the push of a single button, combinations of audio and control circuits. The CALL SIGNAL button {7} enables the signalling function, when the unit is equipped with this option. The PANEL MICRoPHONE enable button {8} selects the front panel gooseneck microphone and deactivates the headset microphone; if no headset is plugged in, PANEL MICRoPHONE only is automatically selected. The SPEaKer ON button {9} turns on the loudspeaker. Note: the headset listen circuit is always on. The MICRoPHONE ON button {10} turns on the microphone in use (headset or panel).

Most of the front panel buttons feature a special momentary / latching dual-action: if a button is pressed quickly, the function will "latch", (turning "on" if off, turning "off" if on); if the button is held slightly longer, the action will be momentary and the function will turn off when the button is released. (Note: This "latching" function can be disabled. See Section 3 for details).


THE MASTER VOLUME {11} control sets the level of the sum of all audio sources going to the left and right side of the stereo headphone and loudspeaker (exceptions: chime and squawk receive levels).

The AUXiliary VOLUME {12} control sets the level of the two auxiliary program audio inputs (and sends it to the MASTER VOLUME control).

The CARBON MICRoPHONE HEADSET jack {13} accepts a standard 3-conductor 1/4" phone plug. The necessary DC excitation voltage is provided to power carbon microphones or their electronic equivalent.

The DYNamic MICRoPHONE HEADSET {14} connector accepts a stereo earphone, dynamic microphone headset.

**FIGURE 1-3
MODEL 802 ADJUSTMENT BOARD**



ADJUSTMENT BOARD: DESCRIPTION AND OPERATION (Figure 1-3)

The Adjustment Board is located to the left of the loudspeaker. Release the board by first pressing and releasing the small rectangular panel (1) on the front panel illustration, and then pulling it forward.

Located on the board are sixteen individual listen level controls {A}, fourteen 4-turn 2-wire intercom balance controls {D}, seven auxiliary function controls {E}, three groups of sixteen audio source assignment switches {B}, eight programming switches {C}, the microprocessor reset button {F}, and the status indicator lamps {G}.

The LISTEN LEVEL controls {A} 1--12 adjust the incoming levels of the twelve primary intercom channels. Compensate for level differences by adjusting these controls.

The BALANCE controls {D} only function in the 2-wire intercom mode. Adjust the BALANCE control on each channel to null your own microphone signal in the loudspeaker or headphones. Channel 13 LISTEN and BALANCE controls are used in the "ISO" function. Channel 14 LISTEN LEVEL and BALANCE controls are reserved for future use. LISTEN LEVEL controls 15 and 16 adjust the levels of the AUXILIARY PROGRAM inputs 1 and 2.

In the Auxiliary Control section {E}, the first control {E1} adjusts the button illumination brightness; the second control {E2} adjusts the loudspeaker level change when the microphone is switched on. The SIDETONE LEVEL {E3} adjusts the loudness of your own microphone signal heard in your own headset. The CHIME LEVEL {E4} sets the volume of the incoming chime signal (when chime option is installed). The SQUAWK LEVEL {E5} sets the volume of the incoming squawk signal (when squawk option is installed). The PANEL MIC GAIN {E6}, and HEADSET MIC GAIN {E7} adjust the gain of the respective microphone preamplifier to compensate for differences in microphone levels or individual's voices.

The ASSIGNMENT SWITCHES {B} assign the 16 primary audio sources in any combination to the left or right side of the stereo headset or to the loudspeaker. These 16 sources are:

- INTERCOM CHANNELS 1-12
- "ISO" listen
- AUXILIARY PROGRAM #1
- AUXILIARY PROGRAM #2
- SPARE

The RESET button {F} is used to reset the microprocessor. This is required when initially installing certain options or making certain programming changes on the Mother Board. The STATUS LAMPS {G} are used for diagnostic purposes.

The PROGRAMMING switches {C} are used to set up various special operating modes. See Figure 2-32A on page 44 for illustration.

REAR PANEL: DESCRIPTION AND OPERATION (See Figure 2-10)

The Model 802 is connected to other Model 802's, other systems, and external equipment using the connections on the Rear Panel.

The LINE {2} connector, ANCILLARY {3} connector, and {8} screw terminal strips are present on a basic Model 802.

The optional IFB {4}, SQUAWK {5}, 4-WIRE {6}, and ISO {7} connectors are installed only as a part of the various options.

The screw terminals {8}, provide connection to the six sets of single-pole double-throw (SPDT=form C) relay contacts, microphone on/off remote control (momentary action only--not alternate action), Model VCP 6 or VCP 12 Iso Control Station, external headset connector, external microphone input, auxiliary program inputs, microphone preamplifier outputs, external loudspeaker, and power input.

The LINE connector {2} contains the balanced audio circuits and keying circuits for intercom channels 1-12, as well as connection to Auxiliary Program Input #2. In normal 2-wire operation, each audio pair functions as a full-duplex two-way communication circuit; while, in the 4-wire mode, the same pairs function as the send portion of each circuit assigned to 4-wire operation.

The ANCILLARY connector {3} connects to: 1) six sets of programmable relay contacts, 2) the microphone on/off remote control, 3) the squawk receive input, and 4) two auxiliary program balanced inputs.

The IFB {4}, SQUAWK {5}, and ISO {7} connectors are plug-in compatible with Model 4010 Central Electronics, Model SQJ1010 Central Junction Interconnect, and Model VIE306 Station Isolate Electronics, respectively.

The 4-WIRE connector {6} contains channels 1-12 4-wire receive circuits, channels 7-12 4-wire talk (send) circuits and channels 7-12 keying circuits.

The optional AUX connector {1} directly accesses the microprocessor via an RS-232 bus, only as a part of custom software applications.

INTERFACING TO OTHER EQUIPMENT

DIRECT: An 802 connects directly to external equipment via the line connector, the back panel terminals and the ANCILLARY connector.

SYSTEM: The Model 862 System Interconnect provides direct connection of up to 12 channels of TW Intercom, as well as audio inputs and outputs, and switching circuits. Signals interfaced via the 862 are common to all 802's in the system.

DIRECT with OPTIONS: An individual 802, equipped with standard options, can connect with Series 4000 IFB System or the TW Intercom Station Isolate System.

SPECIFICATIONS

Color: Gray, Federal Standard 595A: Color #26492
Weight: 18 pounds (8.2 kilograms)
Dimensions: 3.5 inches (89 millimeters) high
19.0 inches (483 millimeters) wide
14.3 inches (363 millimeters) deep
(Excluding connector/microphone and
adjustment board clearances)

Inputs

Dynamic Microphone
Source Impedance 50-1000 ohms
Level -55 dBu nominal

Carbon Microphone
Level -15 dBu nominal
Excitation 10 to 16 milliamperes

Four-Wire Receive Level
-20 \pm 10 dBu into 10 kilohms, balanced/floating

Squawk Input Level 0 \pm 10 dBu into 20 kilohms, unbalanced
Program Input Level 0 \pm 10 dBu into 20 kilohms, balanced/floating

Power 16-20 volts ac rms at 3 amperes maximum
18-26 volts dc at 2 amperes maximum

Outputs

Headphone Level 8 volts pp into 25 ohms
Speaker Level 10 volts pp into 8 ohms
Mic Out Level "LINE" 0 dbu nom., source: 400 ohms, balanced, floating
Mic Out Level "MIC" -54 dBu nom., source: 10 ohms, balanced, floating

Relay Contacts 1 amp, 24 volts dc maximum
0.5 amp, 110 volts ac maximum

Bilateral Line: 10 milliamperes pp max (2V pp/200 ohms)
Driver Outputs 3 milliamperes pp avg (2/3 V pp/200 ohms)

4-Wire Send (Current Source) Output Levels:
10 milliamperes pp max (6V pp/600 ohms)
3 milliamperes pp avg (2 V pp/600 ohms)

Key Outputs (Open Collector): 0.5 amperes, 50 volts dc maximum

MODEL 56-16 POWER SUPPLY

Input: 117 volts ac \pm 10% 50/60 Hertz, 1.7 amps
-234 volts ac \pm 10% 50/60 Hertz, 0.85 amps
Output: 16 volts ac, 3.5 amps

SECTION 2: INSTALLATION

MECHANICAL INSTALLATION The 802 Speaker Master Station is a rack (or console) mountable enclosure, 3.5 inches (89 mm) high by 19.0 inches (483 mm) wide by 14.3 inches (363 mm) deep. The mounting holes are standard E.I.A. spacing. The panel microphone requires a minimum of 5.0 inches (127 mm) front panel clearance, and the adjustment board requires 11 inches (279 mm). Allow an additional 2.0 inches (51 mm) for the rear panel connectors.

When installing this station, allow space for control access, cabling and servicing. Provide space for: cabling service loops, connectors, and cables. If the headset connector is remotely located, allow space between this cable and interfering sources such as TV monitors, power supplies and equipment with internal power supplies.

The Model 56-16 power supply, when used should be mounted at least 1 to 2 feet away from the Model 802 to minimize hum pickup.

ELECTRICAL INSTALLATION/POWER The 802 receives electrical power from either (1) the Model 56-16 ac power supply (supplies 16 vac at 3 amps) or (2) a user supplied system power supply. The power requirement for the Model 802 is 16-20 volts ac rms/3 amperes or 16-28 volts dc 2 amperes. Input power (mains power) to the Model 56-16 is switch selected to either 120 vac $\pm 10\%$ or 230 vac $\pm 10\%$, 50/60 Hz $\pm 10\%$. Connect power to the Model 802 as shown in Figure 2-1.

WARNING For 230 volt operation, change fuse F1, on the Model 56-16, to a 0.375 amps slow-blow 3AG type. For metric style fuses, use part # 2802-0006-00 (metric fuse adapter).

NOTE Always connect the green safety wire from earth or safety ground to the chassis of the Model 802 (TB16-3).




FIGURE 2-1
MODEL 802 POWER SUPPLY CONNECTIONS
802/2nd Ed./October 15, 1986/Page 17

ELECTRICAL INSTALLATION/GROUNDING The Master Station chassis should be connected to earth ground or power line safety ground. Each Master Station is bypassed to its own chassis via a 0.1 microfarad capacitor and 22 kilohm resistor in parallel to prevent interference from radio stations.

ELECTRICAL INSTALLATION/SIGNALS/GENERAL

Model 802 system configurations are:


- 1) All Model 802 Master Station(s)
- 2) Model 802 Master Station(s) & Model 862 System Interconnect
- 3) Model 802 Master Station(s) plus TW Intercom System

In the "All Master Station(s) Configuration" (see Figure 2-2), interconnect the stations using Model 4025 splitter assemblies. Connect the Model 802 LINE connectors (J-101) to the Model 4025 splitter assembly as shown in Figure 2-2. Terminate the system by connecting terminator plug of Figure 2-3 to Model 4025.


In the "Master Station(s) and Model 862 Configuration" (see Figure 2-4), interconnect the stations using either the multiple connectors on the rear of the Model 862, Model 4025 splitter assemblies or a combination of both. Terminate the system by connecting terminator plugs (Figure 2-5) to jacks J5--J8 of the Model 862. Two terminators are required for a 6-channel system. Four terminators are required for a 12-channel system. On a 6-channel system, install terminator plugs in Model 862 "CH 1-2-3" (J5) and "CH 4-5-6" (J6) connectors. On a 12-channel system install terminator plugs in Model 862 "CH 1-2-3" (J5), "CH 4-5-6" (J6), "CH 7-8-9" (J7), and "CH 10-11-12" (J8).

To mechanically secure the cable to the Model 802 rear panel:

- (1) Remove the screw just to the left of J-101,
 - (2) Plug the cable into J-101,
 - (3) Secure the cable connector by screwing the captive screw in the connector into the hole left in step (1), above,
 - (4) Use a cable tie to secure the other side of the connector, using the cable tie loop on the rear panel of the Model 802.
- Caution Using one screw only (and omitting cable tie) to secure cable connector may damage rear panel connector.




**FIGURE 2-2
ALL MASTER STATION SYSTEM**




ALL RESISTORS ARE 200 OHM 1/4 WATT
TERMINATOR PLUG IS A 50-PIN FEMALE CONNECTOR

**FIGURE 2-3
TERMINATOR PLUG**
802/2nd Ed./October 15, 1986/Page 19



**FIGURE 2-4
MASTER STATION SYSTEM AND MODEL 862**



ALL RESISTORS 200 OHM
 ALL CAPACITORS 10uF/50V
 CONNECTOR SHOWN IS A 4-PIN MALE XL TYPE.

**FIGURE 2-5
TERMINATOR PLUG FOR MODEL 862**

The "Master Station plus TW Intercom System Configuration" includes one or more 802's, a Model 862 System Interconnect, and a TW Intercom System (see example system, Figure 2-7). In this system the master stations talk and listen between themselves and the TW user stations. The call light (optional) signals are also sent throughout the system.

This method allows an unrestricted channel assignment switching system to be used on the TW Intercom System. The TW portion of the system, (Figure 2-7), consists of four Model PS31 (or PS-30) power supplies and Model BP-300 user stations. To interface the TW Intercom System to the Model 802 Master Station System, connect PS31 (PS-30) #1 output 1-2-3 to 862 input "CH 1-2-3" (J5). Connect PS31 (PS-30) #2 output 1-2-3 to 862 input "CH 4-5-6" (J6). If a 12-channel master station system is being interfaced, connect PS31 (PS-30) #3 output 1-2-3 to 862 input "CH 7-8-9" (J7) and PS31 (PS-30) #4 output 1-2-3 to 862 input "CH 10-11-12" (J8).

Not all channels need to be connected between the 862 and the PS31's (PS-30)'s. For example, to convert channel 12 on the master stations to be a private channel for communications between 802's only, do not connect pin 3 of the 862's 10-11-12 input connector but terminate instead with a resistor as shown in Figure 2-6. This procedure may be used to isolate any one channel or combination of channels. Note that any channel not connected to an external TW channel must be terminated with a 200 ohm resistor and 10 microfarad capacitor as shown in Figures 2-5 and 2-6. Connect output from the 802's line connector (J-101) to the line inputs on the 862.

To mechanically secure the cable to the Model 802 rear panel:

- (1) Remove the screw just to the left of J-101,
- (2) Plug the cable into J-101,
- (3) Secure the cable connector by screwing the captive screw in the connector into the hole left in step (1), above,
- (4) Use a cable tie to secure the other side of the connector, using the cable tie loop on the rear panel of the Model 802.




FIGURE 2-6
CHANNEL 12 TERMINATION
 802/2nd Ed./October 15, 1986/Page 21




FIGURE 2-7
 MODEL 802/TW INTERCOM SYSTEM BLOCK DIAGRAM
 802/2nd Ed./October 15, 1986/Page 22

Some block diagrams in this manual use codes contained in Table 2-1, Connector Code Table. Note that, in this table, only chassis-mount connectors are specified. Note: All male connectors are colored black.

TABLE 2-1
CONNECTOR CODE TABLE

CODE	PART NO.	CONNECTOR DESCRIPTION
A	XLR-3-31	AUDIO, CHASSIS MT., FEMALE, 3 PIN
B	XLR-3-32	AUDIO, CHASSIS MT., MALE, 3 PIN
C	XLR-4-31	AUDIO, CHASSIS MT., FEMALE, 4 PIN
D	XLR-4-32	AUDIO, CHASSIS MT., MALE, 4 PIN
E	----	MICRORIBBON TYPE, CHASSIS MT., MALE, 50 PIN
F	----	MICRORIBBON TYPE, CHASSIS MT., FEMALE, 50 PIN
G	----	"D" TYPE, CHASSIS MT., MALE, 25 PIN
H	----	"D" TYPE, CHASSIS MT., FEMALE, 25 PIN
J	456	"C" TYPE, CHASSIS MT., MALE, 6 PIN
K	453	"C" TYPE, CHASSIS MT., MALE, 4 PIN
L	----	5-WAY BINDING POST, DUAL ASSEMBLY
M	XLR-5-31	AUDIO, CHASSIS MT., FEMALE, 5 PIN
N	XLR-5-32	AUDIO, CHASSIS MT., MALE, 5 PIN
P	452	"C" TYPE, CHASSIS MT., MALE, 3 PIN
Q	D6F	AUDIO, CHASSIS MT., FEMALE, 6 PIN
R	D6M	AUDIO, CHASSIS MT., MALE, 6 PIN
S	R05-R5M	BNC TYPE, CHASSIS MT., MALE, 5 PIN
T	----	"D" TYPE, CHASSIS MT., FEMALE, 9 PIN
U	----	TERMINGAL, BARE WIRE (WEIDMULLER)
V	----	SCREW TERMINAL, BARRIER STRIP
W	----	PHONE JACK, 2-CIRCUIT, SHORTING & NONSHORTING
X	----	PHONE JACK, 3-CIRCUIT, SHORTING & NONSHORTING
Y	----	PHONO JACK,
AA	----	MINI-JACK, FEMALE




FIGURE 2-8
DARLINGTON KEY OUTPUT




FIGURE 2-9
KEY OUTPUT APPLICATION
802/2nd Ed./October 15, 1986/Page 24

ELECTRICAL INSTALLATION/SIGNALS/FEATURES

KEY OUTPUTS

Twelve logic-type outputs are available at rear-panel line connector, J101. These outputs control relays in the Model 862 System Interconnect, but if your system does not include a Model 862, these outputs may be used directly as control outputs. Pressing one of twelve talk buttons on the front panel of the Model 802 activates one of the twelve key outputs (respectively). Connections to these outputs are shown on sheet 20 of the Model 802 schematic. Figure 2-8 shows a typical output. The darlington transistor output conducts to ground, when activated, and has a maximum rating of 50 volts, 50 milliamperes, dc. Figure 2-9 shows an application of the key output. **Note:** relays should always have a diode to protect the transistor in the Model 802.

RELAY OUTPUTS (See Figure 2-10)

Six form C relay contacts are available on the Model 802 rear panel. The respective relays are programmable from the front panel to operate with front panel pushbutton(s) (See Section 3). Maximum contact ratings are: 1 amp at 24 volts dc, or 0.5 amp at 110 volts ac. **Note:** Applying voltages over 32 volts is not recommended. Relay programming is discussed in section 3.

EXTERNAL MICROPHONE SWITCH (See Figure 2-10)

Connect an external or remote microphone switch to TB7 (using labels above TB7 for exact connection). When the switch is closed the microphone will turn on and will be indicated by the front-panel MIC ON switch being brightened. The remote switch is not alternate action and requires a maintained contact. When the remote switch is off, the microphone may be turned on locally, but when the remote switch is on, the microphone may not be turned off locally.




FIGURE 2-10
MODEL 802 REAR PANEL CONNECTIONS

MODEL 802
MASTER STATION
RTS SYSTEMS, INC.
BURBANK, CALIFORNIA
MADE IN U.S.A.

VCP CONNECTOR (See Figure 2-10)

The rear-panel terminal block, TB8, has connections to interface to a "video-iso" system, and, also, a "squawk" system.

EXTERNAL HEADSET CONNECTOR (See Figure 2-10)

Connect external headphones to TB9. Make sure that the external headphones connections are separate from any microphone connections, or oscillations will occur. TB9 is paralleled with the front-panel headset connector; use only one at a time.

EXTERNAL MICROPHONE CONNECTOR (See Figure 2-10)

An external microphone may be used in place of the front-panel gooseneck microphone by connecting the external microphone to rear-panel terminal block TB10. When using an external microphone, disconnect the front-panel microphone by unplugging connector, P1, from the motherboard.

Electret microphones may also be used with the Model 802. Both 2-wire and 3-wire microphones are accommodated. To use a 2-wire electret microphone, install resistor R3 on the mother board.

PROGRAM INPUTS (See Figure 2-10)

Connect external program inputs to rear-panel terminal blocks TB11 and TB12. These inputs accept line-level balanced audio. Program volume level is controlled by front-panel AUX VOLUME control, adjustment board pots 15 and 16, and front-panel MASTER VOLUME control. Program may be assigned to left headphone, right headphone, or speaker by switches on the adjustment board. Alternatively, Program #2 audio may be injected at the Model 862 System Interconnect to all master stations, or audio appearing at Program input #2 of any Model 802 will appear on all Model 802's.

MICROPHONE OUTPUT CONNECTORS (See Figure 2-10)

Two microphone outputs are provided via rear-panel terminal blocks TB13 and TB14. A rear-panel LEVEL switch selects low level (MIC) or high level (LINE) output. A separate MODE switch for each output determines whether an output is controlled by the MIC ON/OFF switch.

EXTERNAL SPEAKER OUTPUT (See Figure 2-10)

Connect an external speaker to rear-panel terminal block TB15. Since this output is a bridging-type output, **DO NOT LET EITHER SPEAKER LEAD CONTACT GROUND.** The switch next to TB15 turns off the internal speaker .

ELECTRICAL INSTALLATION: HEADSET(S)

HEADSET REQUIREMENTS: A wide range of headset types may be used:

Dynamic microphone headset type: Carbon microphone headset type:

50 to 1000 ohm microphone
25 to 1000 ohm headphone(s)

Standard carbon microphone
25 to 1000 ohm headphone(s)

Use headphones with an impedance of 25 ohms or greater. Low impedance 8 ohm headphones are not recommended. Headphones with good acoustic isolation (20 to 40 dB) improve communication in high ambient noise environments, and allow the user to use the headphones at a less tiring, lower volume.

In the headset connecting cable, prevent coupling between the microphone and headphone leads by using a shielded, twisted pair for the microphone, and a separate, twisted pair for the headphones. Do not allow headphone ground to contact microphone ground or shield. Tie the shield to microphone ground or "mic low". The headset cable can be made longer when the microphone and headphone pairs are physically separated. The wider the separation, the longer the cable length which may be used. Estimated maximum usable headphone cable lengths are as follows:

Single cable, two shielded twisted pair: 10 feet (3.05 m).
Dual ribbed cable, two shielded twisted pair: 30 feet (9.14 m).
Separate cables, shielded twisted pair in each: 50 feet (15.24 m).
Balanced microphone input: up to 100 feet (30.48 m).

HEADSET CONNECTIONS

Dynamic Microphone headset connector: XLR-5-31 type receptacle

Input level: -55 dBV nominal

Output level to headphone: 10 volts peak-to-peak open circuit.

- Pin 1 - Microphone low
- Pin 2 - Microphone high
- Pin 3 - Headphone low
- Pin 4 - Left Headphone high
- Pin 5 - Right Headphone high

Carbon Microphone headset connector: Standard 1/4" Tip-Ring-Sleeve (TRS) Phone Jack

Input level: -15 dBV nominal

Output to Headphone: 10 volts peak-to-peak open circuit.

- Tip - Carbon Microphone
- Ring - Headphone
- Sleeve - Common/ground

ELECTRICAL INSTALLATION/SIGNAL/MODEL 802 TO MODEL 801/MODEL 860

If the Model 802 has been equipped with an "801 emulate" option, a connector on the rear panel of the Model 802 plugs directly into an "801" type system.

If it is required that a non-801 emulate type 802 be used in an "801" type system, follow the directions below.

Case 1: Six channels of intercom, no SA's, no IFB's, no Slate, no Monitor Mute: Use a standard six channel Model 802 to connect to a six channel "801" system. A wiring diagram for connecting a 6-channel Model 802 to an 801 system is shown in Figure 2-11. Install button legends per Figure 2-12.

Case 2: Six channels of intercom, SA's, IFB's, Slate, Monitor Mute: Use a 12-channel Model 802 (equipped with the Talk option) and connect using the wiring diagram in Figure 2-13. Install button legends per Figure 2-14. This wiring will operate all relays in the 860. In a 12-channel 802, program one of the relays to activate when SLATE MIC is pressed. This relay is equivalent to the slate-mic/radio-telephone relay available on J2 of the Model 801.

Program another relay to activate when SPKR MUTE is pressed. This relay is equivalent to the monitor mute relay contacts available at J4 on an 801. This relay may also be programmed to activate when an SA button is pressed. Thus if SA1 is used as a studio announce, the studio speaker nearest the 802 may be muted via the relay when its SA1 button is pressed. This will prevent feedback squeals.

Model 801's may also be used in an 802/862 system. Make connections between the systems as shown in Figure 2-15. Be sure that termination is provided by only one system. Note that some connections are optional. The standard connections allow the six talk and listen channels of the 801 to communicate with the first six talk and listen channels of the 802. The optional connections interface the next five channels of the 801 to channels 7 - 11 of the 802. SA and IFB channels on the 801 can only talk and can not listen. SLATE is a 2-way line and will work to both talk and listen. Listen level on the SLATE line is controlled by the EXT. 2 level knob. The key connections allow the 801 to operate relays 7 - 11 in the 862.

For more information on 801/860 systems, see the 801 technical manual TM2604.




FIGURE 2-11
CASE 1: SIX CHANNEL 802 TO SIX CHANNEL 801 INTERCONNECTION





FIGURE 2-12
CASE 1: FRONT PANEL BUTTON LEGEND
 802/2nd Ed./October 15, 1986/Page 30

FROM MODEL 802
OR
MODEL 802
NOTE : THIS CONNECTOR IS
SPECIFIED J101 WHEN FROM
MODEL 802 AND IS SPECIFIED
J1, J2, J3, OR J4 WHEN FROM
MODEL 802.
PLUG IS FEMALE WHEN FROM
MODEL 802.



TO JS ON
MODEL 801
OR
TO MODEL 800

FIGURE 2-13
CASE 2: TWELVE CHANNEL 802 TO SIX CHANNEL 801 INTERCONNECTION
802/2nd Ed./October 15, 1986/Page 31




FIGURE 2-14
CASE 2: FRONT PANEL BUTTON LEGEND




FIGURE 2-15
USING AN MODEL 801 IN AN MODEL 802 SYSTEM
802/2nd Ed./October 15, 1986/Page 32

ELECTRICAL INSTALLATION/SIGNALS/MODEL 802/TELEPHONE

The Model 802 may be interfaced to telephone lines as follows.

Method 1: Connect a party-line (PL) channel from either one 802 or from an 862 to either a dry or wet phone line via a step-up transformer as shown in Figure 2-16 (Figure 2-10 in 801 manual). Terminate the phone line with an 820 ohm resistor across the transformer secondary (phone line side). The transformer is large enough so that it can be directly connected across a "wet" line (line with dc current) with negligible ac performance degradation; the secondary is low enough resistance so that it will "hold" the line.

Method 2: Connect a TWI-222T-telco interface unit as in Figure 2-17.

Method 3: Connect a TWI-326 interface unit using Figure 2-18. Note: the 200 ohm resistor termination is not required if a PS 31 (PS-30/60) is also connected.

Method 4: Connect a Model 802 with 4-wire option (OPT802-C2, or OPT802-C3) to a TWI-326 as shown in Figure 2-19. This method will work better than the two methods above. Note: Termination must be provided.




FIGURE 2-16
METHOD 1: MODEL 802 TO TELEPHONE INTERCONNECTION





FIGURE 2-17
METHOD 2: MODEL 802 TO TELEPHONE INTERCONNECTION
 802/2nd Ed./October 15, 1986/Page 34



(ALSO SEE MODEL TWI-328 MANUAL)

FIGURE 2-18
METHOD 3: MODEL 802 TO TELEPHONE INTERCONNECTION




FIGURE 2-19
METHOD 4: MODEL 802 TO TELEPHONE INTERCONNECTION
 802/2nd Ed./October 15, 1986/Page 35

ELECTRICAL INSTALLATION/SIGNALS/MODEL 802/SERIES 4000 IFB

The Model 802 may be used in either of two ways with the 4000 series IFB system. Method "A" uses a line-level unswitched microphone output from the Model 802 to drive Models 4001, 4002, or 4003 IFB Control Stations. Method "B" emulates either a Model 4001 or 4002 IFB control station and requires no external parts, but it does require: 1) the installation of one or two IFB option boards, 2) that mother board programming switch(es) be actuated and 3) a microprocessor reset be executed.

To use Method "A", connect the Model 802 (rear panel) MIC OUTPUT 1 or MIC OUTPUT 2 to Models 4001, 4002, or 4003 IFB Control Stations. Use the instructions for "Line-level inputs" in the IFB Technical Manual, TM2594. Note that, on the 4000 series control station, R11 must be removed and a trace cut. Interconnect the IFB system and configure the 4001, 4002, or 4003 for power input and priority as described in the IFB Technical Manual TM2594 and Figures 2-20A and 2-20B. Move the 802's LEVEL switch to LINE and the MODE switch to UNSW. Do not connect the shield at the 802 end of the cable.

Method "B" IFB (See Figures 21, 22, 23, and 24) requires both an option base (OPT802-A1) and IFB option(s). To emulate a model 4001 IFB control station option OPT802-G1 must be installed. To emulate a model 4002 IFB control station, both the OPT802-G1 and OPT802-G5 options must be installed. Note that if both IFB options are installed the "Iso" option can not be installed. If the IFB priority needs to be changed, consult the IFB Technical Manual, TM 2594.

TYPICAL CONFIGURATION #1




FIGURE 2-20A
 METHOD "A": MODEL 802 TO IFB CONNECTION (4 IFB's)
 802/2nd Ed./October 15, 1986/Page 37

TYPICAL CONFIGURATION #2




FIGURE 2-20B
 METHOD "A": MODEL 802 TO IFB CONNECTION (8 IFB's)
 802/2nd Ed./October 15, 1986/Page 38




FIGURE 2-21
METHOD "B": MODEL 802 TO IFB CONNECTION (4 IFB's)
 802/2nd Ed./October 15, 1986/Page 39

TYPICAL CONFIGURATION #2




FIGURE 2-22
 METHOD "B"; MODEL 802 TO IFB CONNECTION (8 IFB's)
 802/2nd Ed./October 15, 1986/Page 40




FIGURE 2-23
MODEL 802 FRONT PANEL BUTTON ARRANGEMENT FOR 4 IFB's




FIGURE 2-24
MODEL 802 FRONT PANEL BUTTON ARRANGEMENT FOR 8 IFB's
802/2nd Ed./October 15, 1986/Page 41

ELECTRICAL INSTALLATION/SIGNALS/SERIES 1000 SQUAWK

The Model 802 may be used in either of two ways with the series 1000 squawk system. Method "A" requires an external model MCP-1010 squawk station that is connected to use the microphone and speaker in the 802. Method "B" emulates a model MCP-1010 squawk station with no external parts required.

For Method "A" squawk, connect MIC OUTPUT 1 or MIC OUTPUT 2 of the 802 to the EXTERNAL LINE LEVEL MICROPHONE INPUT of the MCP-1010 as shown in Figure 2-27. Connect the MCP-1010's OUTPUT TO CONFERENCE LINE to the SQUAWK input at TB8 on the 802.

Incoming audio level from the MCP-1010 is controlled by the SQUAWK level adjust on the 802's pull-out adjustment board only and is not affected by 802 or MCP-1010 front-panel level control or 802/MCP-1010 front-panel speaker switch.

For Method "B" squawk, the SQUAWK option must be installed. Two squawk options are available. The first option OPT802-F1 will emulate only the first six channels of an MCP-1010. The second option OPT802-F5 adds on to the first option so that all ten channels on an MCP-1010 are emulated. Either option requires the OPT802-A1 option base (See Figures 25, 26, and 28).

Incoming audio level is controlled by the adjustment board squawk level pot only and is not affected by front-panel VOLUME control.




FIGURE 2-25
MODEL 802 FRONT PANEL BUTTON ARRANGEMENT FOR 6 SQUAWK 's




FIGURE 2-26
MODEL 802 FRONT PANEL BUTTON ARRANGEMENT FOR 10 SQUAWK 's
802/2nd Ed./October 15, 1986/Page 43





FIGURE 2-27
METHOD "A": MODEL 802 TO SQUAWK CONNECTION
 802/2nd Ed./October 15, 1986/Page 44



NOTES: 1 THIS STATION MAY BE IN ANY POSITION (1 THROUGH 10)
 MODEL 802'S MAY ALSO BE USED IN MORE THAN ONE POSITION.

FIGURE 2-28
METHOD "B": MODEL 802 TO SQUAWK CONNECTION
 802/2nd Ed./October 15, 1986/Page 45

ELECTRICAL INSTALLATION/SIGNALS/CAMERA (VIDEO) ISO

The Model 802 may be used in either of two ways with the VIE-306 video iso electronics. Method "A" requires a model VCP-6 or VCP-12 video iso control panel. Method "B" will emulate a model VCP-6 video control panel station and requires no external parts.

Method "A" video iso requires an external VCP-6 or VCP-12 video control panel. Connect the video control panel to the 802 rear-panel VCP CONN terminal block as shown in Figure 2-30.

Method "B" video iso will emulate a model VCP-6. To use this option ISO option OPT802-H1 must be installed along with option base OPT802-A1.

Enable ISO option "B" by moving switch S125-4 on the mother board to ON (See Figure 2-32) and pushing the RESET button on the adjustment board. Connect output from rear-panel ISO connector J106 to the VIE-306 central electronics as shown in Figure 2-31.

With either ISO option "A" or "B", ISO DRIVEN LISTEN DISABLE may be enabled. This option will mute all incoming party line calls when an ISO channel is selected. To enable this option, move switch S125-5 on the mother board to ON as shown in Figure 2-32. In either case, outgoing party-line channels are disabled during video iso.




FIGURE 2-29

MODEL 802 FRONT PANEL BUTTON ARRANGEMENT FOR ISO (METHOD "B")
802/2nd Ed./October 15, 1986/Page 46




FIGURE 2-30
METHOD "A": MODEL 802 TO ISO CONNECTION
 802/2nd Ed./October 15, 1986/Page 47




FIGURE 2-31
METHOD "B": MODEL 802 TO ISO CONNECTION
802/2nd Ed./October 15, 1986/Page 48




FIRMWARE <u>V & 3.0</u>	FIRMWARE <u>4.2, 4.3, 4.5</u>	FIRMWARE <u>4.6, 4.7</u>
<p style="text-align: center;">8 701</p> 	<ol style="list-style-type: none"> 1. CALL ANSWER 2. INSTANT MIC ON 3. IFB on/off 4. IFB 8/4 or ISO 12/6 5. PRESET EXCLUSIVE 6. Not Used 7. COLD START 8. SET-UP DISABLE 	<ol style="list-style-type: none"> 1. Not Used 2. Not Used 3. IFB on/off 4. IFB 4/8 or ISO 6/12 5. PRESET EXCLUSIVE 6. LISTEN FOLLOW TALK 7. COLD START 8. SET-UP DISABLE

FIGURE 2-32A
ADJUSTMENT BOARD COMMAND SWITCH

FIRMWARE <u>V & 3.0</u>	
<p style="text-align: center;">8 126</p> 	<ol style="list-style-type: none"> 1. CALL LIGHT TIME OUT 2. TALK 7-12 ENABLE 3. ON=801 emulate 4. ISO ENABLE 5. ISO LISTEN DISABLE 6. IFB ENABLE 7. IFB SELECT 8. IFB TALK DISABLE

FIRMWARE <u>4.0, 4.1, 4.2, 4.3, 4.5, 4.6</u>	
<p style="text-align: center;">8 126</p> 	<ol style="list-style-type: none"> 1. CALL LIGHT TIME OUT 2. OFF=1-6 talk, ON=7-12 talk 3. ON=801 emulate 4. ISO ENABLE, OFF=external contact, ON=buttons 5. ON=disable listen buttons when ISO active 6. ON=ISO enable 7. Not Used 8. ON=disable talk buttons when IFB active


FIRMWARE <u>4.7</u>	
<p style="text-align: center;">8 126</p> 	<ol style="list-style-type: none"> 1. CALL LIGHT TIME OUT 2. OFF=1-6 talk, ON=7-12 talk 3. ON=801 emulate 4. ISO ENABLE, OFF=external contact, ON=buttons 5. ON=disable listen buttons when ISO active 6. ON=ISO enable 7. Not Used 8. ON=disable talk buttons when IFB active

FIGURE 2-32B
MOTHERBOARD DIP SWITCH ASSIGNMENTS
802/2nd./October 15, 1986/Page 49




FIGURE 3-1
MODEL 802 FRONT PANEL PROGRAMMING BUTTONS

Model 802 SPECIAL PURPOSE Programming Mode Functions
By Karen Hultgren

The SPECIAL PURPOSE programming mode allows the user to choose additional operating features, described below. The description includes instructions for the user to implement the features.

BUTTON LOCK **BUTTON LOCK** (formerly **BUTTON INHIBIT**) is used to lock buttons **ON** or **OFF**.

To lock **ON**: First clear display, then select button(s) you want locked **ON**. Go into **SET UP MODE**, select **SPECIAL PURPOSE**, then **BUTTON LOCK**. Reselect the same buttons you want locked **ON**. After you clear from **SET UP MODE**, these buttons will stay **ON** and cannot be turned **OFF** or programmed for any other function except keying relays. You cannot lock **ON** **PRESETS**.

To Lock **OFF**: Clear display and go into **SET UP MODE**. Select **SPECIAL PURPOSE**, then **BUTTON LOCK**. Select button(s) you want locked **OFF**. Clear from **SET UP MODE** and the selected switches cannot be turned **ON**. If you'd like to lock **OFF** some buttons but have a **PRESET** turn them **ON**, program the **PRESET** first and then **BUTTON LOCK**.

INSTANT MIC **INSTANT MIC** activates **MIC ON** with any usable **TALK** button. Standard units can only use **TALK 1** through **TALK 6**. Units with **B3** option (**TALK Channels 7** through **12**) can use **TALK 1** through **TALK 12**.

BILAT* SELECT **BILAT SELECT** can turn **ON** a normally unused bilat with a button on the front panel. Go into **SET UP MODE**, select **SPECIAL PURPOSE**, then **BILAT SELECT**. Buttons will flash the available bilats, refer to Appendix B 4.7 software summary, page 8. Now, assign a button to control that bilat.

TOTAL MUTE **TOTAL MUTE** is used to turn **OFF** all other buttons keyed **ON** with the touch of one button on the front panel. Only one button can be programmed for this function and when programmed cannot be used for any other purpose.

* Bilat means bilateral current source used as a two to four wire converter (RTS Systems patent number 4,358,644: "BILATERAL CURRENT SOURCE FOR A MULTITERMINAL INTERCOM").

Model 802 SPECIAL PURPOSE Programming Mode Functions
By Karen Hultgren

CHIME SELECT, AUTO LISTEN, and AUTO TALK are used with the CALL Option only.

CHIME SELECT CHIME SELECT is used with Chime Option, E1, only. You have a choice of several chime tones which are Dissonant Tone, Bell Tone, Sweep Tone, and no tone. Only one tone can be used at a time. Normally, the 802 uses the Bell Tone which sounds after the software version is shown on the 802 front panel after "power up" or RESET.

To change chime tone, go into SET UP MODE. Select SPECIAL PURPOSE, then CHIME SELECT. Select desired chime tone whose button locations are shown in Appendix B 4.7 software summary, page 7. Push CALL SIGNAL button to hear that tone. You'll now be out of the SET UP MODE because the CALL SIGNAL button doubles as the SET UP button.

To turn Off the chime tones, go into SET UP MODE, select SPECIAL PURPOSE and then CHIME SELECT. The available chime tone buttons will flash, one being out of phase with the others, push that button so all the buttons flash together.

Note: If the selected Chime is too loud or too soft, pull out the adjustment board and adjust the "Chime Level" pot.

AUTO LISTEN AUTO LISTEN functions as follows, when a person at a location remote to a given 802 pushes his CALL transmit button, a call signal is received at the 802. The channel receiving the call signal will key ON that channel's LISTEN button which will remain ON as long as the person at the remote location holds down their CALL transmit button. This allows the caller to vocally announce their call as well as send the call signal.

AUTO TALK AUTO TALK functions the same as AUTO LISTEN except both the TALK and MIC ON buttons will be keyed ON instead of the LISTEN buttons. This allows the 802 operator to talk back to the person at a remote location without touching any buttons.

Model 802 SPECIAL PURPOSE Programming Mode Functions
By Karen Hultgren

EXT. CONTACT The EXTERNAL CONTACT formerly operated only the MIC ON switch. The EXTERNAL CONTACT is now programmable with the default state operating the MIC ON switch (which means that the MIC ON will not be keyed ON when this program is used). Programming the EXTERNAL CONTACT allows the EXTERNAL MIC switch contacts (TB7) located on the 802 rear panel, to be used to key ON a 802 front panel button. Only one button can be programmed for this function. You can, however, program a PRESET to turn ON a group of buttons. To do that, program your PRESET first, then program the EXT. CONTACT to turn ON that PRESET. To turn ON the MIC ON as well, see the INSTANT MIC programming feature, above.

TALK TURNS ON LISTEN TALK TURNS ON LISTEN functions as whenever a particular TALK channel button is pushed ON, the TALK's corresponding LISTEN button will be automatically keyed ON. The LISTEN button will stay ON until the 802 operator pushes it OFF or the TALK button is pushed OFF.

TALK TURNS OFF LISTEN TALK TURNS OFF LISTEN functions as whenever a particular TALK channel button is pushed ON, the TALK's corresponding LISTEN button, if ON, will be automatically keyed OFF. The LISTEN button will stay OFF until the operator pushes it ON or the TALK button is pushed OFF.

APPENDIX A
SUMMARY OF 802 SOFTWARE VERSIONS

Version 4.7

Added two features:

- * (1) TALK key turns on corresponding LISTEN key
- * (2) TALK key turns off corresponding LISTEN key

Version 4.6

Added features:

- * Choice of 6 or 10 squawks
- * Allows assigning of unused bilats to buttons
- * Displays version number of software during power-on
- * Ability to program a total mute button
- * Programmable auto listen-on when receiving a call
- * Auto-Call now programmable on individual buttons
- * Choice of 3 chime tones
- * External (rear panel) mic contact can be programmed to any button
- * Exclusive talk/listen feature:
 - 1 talk/listen pair at a time

NOTES on Version 4.6:

1. Versions 4.5/4.6 are the first to use four EPROM's, previous versions used three EPROM's.
2. Bilat 13/14 talk/listen gates not lifted/saved, (For example: during ISO).

(Continued)

APPENDIX A (Continued)

SUMMARY OF 802 SOFTWARE VERSIONS (Continued)

Version 4.5

Same as Version 4.6, but not released because of a bug: External Iso doesn't key on the MIC.

Version 4.4

This version never issued.

Version 4.3

Correct minor bugs in version 4.2.

Version 4.2

Added features:

- * Added Global Reset button for VCP6A and VCP12A options
- * Instant mic is now programmable to individual buttons

Version 4.1

Added features:

- * Both ISO and IFB moved to right side of panel
- * Any button can be programmed to be ignored

APPENDIX B.4.6

DOCUMENTATION SUMMARY SOFTWARE VERSION 4.6

MOTHER BOARD DIP SWITCH ASSIGNMENTS

1. Call light time-out selection.
2. OFF = 1-6 talks, ON = 7-12 talks.
3. ON = 801 emulation.
4. ISO select. OFF = external contact, ON = buttons.
5. ON = disable listen buttons when ISO active.
6. ON = ISO system enabled.
7. Not used.
8. ON = disable talk buttons when IFB active.

ADJUSTMENT BOARD DIP SWITCH ASSIGNMENTS

1. Not used (old auto-call).
2. Not used (old instant mic).
3. ON = IFB system enabled.
4. Number of IFB's or ISO's. OFF = 6, ON = 12.
5. Only one preset on at a time [INTERLOCKING SWITCH ACTION].
6. When talks active, only corresponding listens can be active.
7. ON = Always "cold start".
8. ON = Disable setup mode.

SQUAWK BOARD DIP SWITCH ASSIGNMENTS

1. OFF = up to 6 squawks, ON = up to 10 squawks.
2. ON = SQUAWK system enabled.
3. Adjusts which buttons have squawk.
4. Adjusts which buttons have squawk.
5. Saves talk when squawk used.
6. Saves listen when squawk used.

CHIME CHOICES

1. Dissonant tone (DISS).
2. Bell.
3. Sweep tone (PHaSoR).

APPENDIX B.4.6 (Continued)

SPECIAL PURPOSE FUNCTIONS

BUTN	INS-	UN-	TOT-	CHME	AUTO	AUTO	EXT.				
LOCK	TANT	USED	AL				CON-				
	MIC	BLTS	MUTE	SEL.	LSTN	TALK	TACT				

PRE	PRE	PRE	PRE	CALL	PNL	SPKR	MIC	-	-		
SET	SET	SET	SET					o	o	o	
1	2	3	4	*	MIC	ON	ON	-	-		

Setup

CHIME SELECT

								CHME	CHME	CHME	
								1	2	3	
								DISS	BELL	PHSR	

PRE	PRE	PRE	PRE	CALL	PNL	SPKR	MIC	-	-		
SET	SET	SET	SET					o	o	o	
1	2	3	4	*	MIC	ON	ON	-	-		

Setup

APPENDIX B (Continued)

UNUSED BILATERAL CURRENT SOURCE SELECTION

				TG	TG	ISO	LG	OLD	LG	LG	LG	Top
				13	14	TLK	13	ISO	14	15	16	But
												ton
												Row
				^	^	^	^	^	^	^	^	

Corresponding Circuit PIO2|PIO2|PIO1|PIO2|PIO1|PIO2|PIO2|PIO2|
 Points to top row 3 | 3 | 5 | 2 | 5 | 2 | 2 | 2 |
 Buttons. BIT0|BIT1|BIT6|BIT4|BIT7|BIT5|BIT6|BIT7|

VERSION IDENTIFICATION (VERSION 4.62 ILLUSTRATED)
 (OCCURS ON POWER-UP)

			XXXX									
1	2	3	XXXX	5	6	7	8	9				
					XXXX							
1	2	3	4	5	XXXX	7	8	9				

PRE	XXXX	PRE	PRE		PNL	SPKR	MIC		-	-	
SET	XXXX	SET	SET	CALL	MIC	ON	ON		o	o	o
1	XXXX	3	4		MIC	ON	ON		-	-	
1	2	3	4	5	6	7	8				

XXXX
 XXXX <----- indicates a lit button.
 XXXX

APPENDIX B.4.7

DOCUMENTATION SUMMARY SOFTWARE VERSION 4.7

MOTHER BOARD DIP SWITCH ASSIGNMENTS

1. Call light time-out selection.
2. OFF = 1-6 talks, ON = 7-12 talks.
3. ON = 801 emulation.
4. ISO select. OFF = external contact, ON = buttons.
5. ON = disable listen buttons when ISO active.
6. ON = ISO system enabled.
7. Not used.
8. ON = disable talk buttons when IFB active.

ADJUSTMENT BOARD DIP SWITCH ASSIGNMENTS

1. Not used (old auto-call).
2. Not used (old instant mic).
3. ON = IFB system enabled.
4. Number of IFB's or ISO's. OFF = 6, ON = 12.
5. Only one preset on at a time.
6. When talks active, only corresponding listens can be active.
7. Always "cold start".
8. Disable setup mode.

SQUAWK BOARD DIP SWITCH ASSIGNMENTS

1. OFF = up to 6 squawks, ON = up to 10 squawks.
2. ON = SQUAWK system enabled.
3. Adjusts which buttons have squawk.
4. Adjusts which buttons have squawk.
5. Saves talk when squawk used.
6. Saves listen when squawk used.

CHIME CHOICES

1. Dissonant tone (DISS).
2. Bell.
3. Sweep tone (PHaSoR).

APPENDIX B.4.7 (Continued)

SPECIAL PURPOSE FUNCTIONS

BUTN	INS-	UN-	TOT-	CHME	AUTO	AUTO	EXT.	TALK	TALK		
LOCK	TANT	USED	AL				CON-	ENAB	DIS		
	MIC	BLTS	MUTE	SEL.	LSTN	TALK	TACT	LSTN	LSTN		

PRE	PRE	PRE	PRE	CALL	PNL	SPKR	MIC	-	-		
SET	SET	SET	SET					o	o	o	
1	2	3	4	*	MIC	ON	ON	-	-		

Setup

CHIME SELECT

										CHME	CHME
										1	2
										DISS	BELL
											PHSR

PRE	PRE	PRE	PRE	CALL	PNL	SPKR	MIC	-	-		
SET	SET	SET	SET					o	o	o	
1	2	3	4	*	MIC	ON	ON	-	-		

Setup

APPENDIX B.4.7 (Continued)

UNUSED BILATERAL CURRENT SOURCE SELECTION

				TG	TG	ISO	LG	OLD	LG	LG	LG	Top
				13	14	TLK	13	ISO	14	15	16	But
												ton
												Row
				^	^	^	^	^	^	^	^	

Corresponding Circuit Points to top row Buttons.

PIO2	PIO2	PIO1	PIO2	PIO1	PIO2	PIO2	PIO2
3	3	5	2	5	2	2	2
BIT0	BIT1	BIT6	BIT4	BIT7	BIT5	BIT6	BIT7

VERSION IDENTIFICATION (VERSION 4.7 ILLUSTRATED)
(OCCURS ON POWER-UP)

			XXXX								
1	2	3	XXXX	5	6	7	8	9			
						XXXX					
1	2	3	4	5	6	XXXX	8	9			

PRE	PRE	PRE	PRE		PNL	SPKR	MIC	-	-	
SET	SET	SET	SET	CALL				o	o	o
1	2	3	4		MIC	ON	ON	-	-	
1	2	3	4	5	6	7	8			

XXXX
XXXX ←----- indicates a lit button.
XXXX

APPENDIX C

MODEL 802 MASTER STATION - OPTION NUMBERING SYSTEM AND ORDERING SYSTEM

Each option for the 802 is listed as a separate model number (derived from the coding system below) which always starts with "OPT802-" followed by a suffix containing both a letter and a number. (i.e. OPT802-B1).

The suffix letter designates what the option is:

A Option Base	J (future)	S (future)
B Talk	K (future)	T (future)
C 4-wire	L (future)	U (future)
D Signal	M (future)	V (future)
E Chime	N (future)	W (future)
F Squawk	O Not to be used	X (future)
G IFB	P (future)	Y (future)
H ISO	Q Not to be used	Z Custom
I Not to be used	R (future)	

The suffix number designates how the option is to be sold/installed:

0	not installed (sold for field installation or as a spare)
1	factory installed, no assignment required
2	factory installed, in channels 1-6
3	factory installed, in channels 7-12
4	
5	factory installed, as secondary (additional) option (i.e. upgrade to: ten squawk channels; IFB 4002
6	not installed, as secondary (additional) option
7	
8	
9	special instructions required

(Continued)

APPENDIX C

MODEL 802 MASTER STATION - OPTION NUMBERING SYSTEM AND ORDERING SYSTEM

(Continued)

OPTION NAME/ NUMBER	DESCRIPTION
---------------------------	-------------

The RTS Order Acknowledgement ("OA") lists each individual option as a separate line item, normally listed directly below the associated 802.

Ordering example:

Quantity	Model	Description
1	802	Master Station
1	OPT802-A1	Option Base, installed
1	OPT802-B3	Talk, installed
1	OPT802-C3	4-Wire, installed, ch 7-12
1	OPT802-E1	Chime, installed
1	OPT802-G1	IFB 4001, installed

"OPTION BASE": REQUIRED TO SUPPORT CERTAIN OPTIONS (INDICATED BELOW).
NOTE: only one "OPTION BASE" is required per individual 802.)

OPT802-A0	Option Base, not installed
OPT802-A1	Option Base, installed

"TALK" OPTION: ADDS CIRCUITRY TO CHANNELS 7-12

OPT802-B0	TALK, not installed
OPT802-B3	TALK, installed

"4-WIRE" OPTION: ADDS 4-WIRE CAPABILITY TO SIX CHANNELS

OPT802-C0	4-Wire, not installed
OPT802-C2	4-Wire, installed, ch 1-6
OPT802-C3	4-Wire, installed, ch 7-12

(NOTE: OPTION C3 REQUIRES "TALK" OPTION B1)

(Continued)

APPENDIX C

MODEL 802 MASTER STATION - OPTION NUMBERING SYSTEM AND ORDERING SYSTEM

(Continued)

OPTION NAME/ NUMBER	DESCRIPTION
---------------------------	-------------

"SIGNAL" OPTION: ADDS CALL SIGNALING CAPABILITY TO SIX CHANNELS

OPT802-D0	Signal, not installed
OPT802-D2	Signal, installed, ch 1-6
OPT802-D3	Signal, installed, ch 7-12

(NOTE: REQUIRES "OPTION BASE" A1)
(NOTE: OPTION D3 ALSO REQUIRES "TALK" OPTION B1)

"CHIME" OPTION: GENERATES AUDIBLE OUTGOING AND INCOMING SIGNAL

OPT802-E1	Chime, installed, factory only
-----------	--------------------------------

(NOTE: REQUIRES "SIGNAL" OPTION D2 OR D3)

OPTION NAME/ NUMBER	DESCRIPTION
---------------------------	-------------

"SQUAWK" OPTION: PROVIDES DEDICATED LINE INTERCOM CAPABILITY
(and MODEL 810 emulate).

OPT802-F0	Squawk, not installed
OPT802-F1	Squawk, installed, ch 1-6,
OPT802-F5	Squawk, installed, ch 7-10

(NOTE: REQUIRES "OPTION BASE")
(NOTE: OPTION F5 ALSO REQUIRES OPTION F1)

(Continued)

APPENDIX C

MODEL 802 MASTER STATION - OPTION NUMBERING SYSTEM AND ORDERING SYSTEM

(Continued)

"IFB" OPTION: EMULATES A MODEL 4001 OR MODEL 4002 IFB CONTROL STATION

OPT802-G0 IFB, not installed
OPT802-G1 IFB, 4001, (IFB 1-4, SA 1)
OPT802-G5 IFB, 4002, (IFB 5-8, SA 2)

(NOTE: REQUIRES "OPTION BASE")

(NOTE: OPTION G5 ALSO REQUIRES OPTION G1)

(NOTE: G1 AND G5 ARE BOTH INSTALLED)

"ISO" OPTION: EMULATES A MODEL VCP6A STATION ISO CONTROL PANEL

OPT802-H0 ISO, VCP6A, not installed
OPT802-H1 ISO, VCP6A, installed

(NOTE: REQUIRES "OPTION BASE")

End Software 4.7 update

SECTION 3: INSTRUCTIONS FOR PROGRAMMING THE MODEL 802

Introduction

There are two kinds of programming functions on the Model 802: Hardware and software. The hardware programming is accomplished via "dip switches" and by plugging in option boards. The software programming is accomplished via the front panel buttons.

HARDWARE FUNCTIONS

The hardware "dip switches are located on:

- The motherboard, near the back panel.
- The adjustment board at the very back.
- The Talk/Squawk Option board.

The option boards that effect programming are:

- The Talk/Squawk Option board(s).
- The Signaling Option board(s)...(Also called the "Call Light" Option boards).

Plugging in the Talk/Squawk Option board and setting the dip switches on it and the motherboard for "Squawk" functions causes the Model 802 to operate in the "Squawk" mode.

Plugging in the Signaling (Call Light) Option board activates the Signaling Option.

DIP SWITCHES

The adjustment dip switch assembly has an eight function programming capability. See Figure 2-32A for illustration.

The motherboard board dip switch assembly has an eight function programming capability. See Figure 2-32B for the present function assignments.

SEE ADDENDUM FOR THE SOFTWARE FUNCTIONS

SET-UP MODE (See Figure 3-1)

To program the Front Panel functions, you must first enter the SET-UP mode. The SET-UP mode is entered by holding the CALL SIGNAL BUTTON {7} for about three seconds. When the SET-UP mode is entered, the microprocessor first stores the existing front panel settings in a temporary "buffer" memory, then clears the front panel. The SET-UP mode is indicated by the SET-UP MODE (CALL SIGNAL) button being steadily illuminated, and this is the only mode in which this button remains steadily illuminated. After entering the SET-UP MODE, the "valid" selection buttons will flash to allow you to select the function that you want to program. Only buttons applicable to the standard functions and installed options will flash. In general, during the SET-UP process, the microprocessor indicates via flashing or winking buttons, the step-by-step procedure to follow.

If, after entering the SET-UP mode, no button is pressed within 13 seconds, the Model 802 will exit or leave the SET-UP mode and return to normal operation. If, however, a selection is made, the unit will remain in SET-UP mode until intentionally exited. In addition, the selected function button will illuminate steadily, indicating what is being programmed, until programming has been completed and stored in memory. After selection, the buttons which are valid selections within the particular programming mode will "wink" ("wink" here, means that the lamp brightens or dims quickly rather than "flashing" half on/ half off). The microprocessor accepts commands only from valid buttons.

PRESET programming function (See Figure 3-1)

The PRESET programming function enables any one or combination of the circuits controlled by the twenty-four selection buttons {4} to be assigned to, and be activated by, one or more of the four PRESET buttons {6}. A simple example would be assigning all of the TALK circuits to PRESET #4, making PRESET #4 an "ALL TALK" button.

To program an "ALL TALK" button using the PRESETS programming function:

- 1) Enter the "SET-UP MODE",
- 2) Choose PRESETS by pushing the PRESETS (PRESET 1) button,
- 3) Choose PRESET 4 by pushing PRESET 4,
- 4) Select all talks by pushing each of the six (or 12) talk buttons {4A}, {4B},
- 5) Push PRESET 4 again to store that setting in the PRESET 4 memory and continue programming; or push the SET-UP MODE (CALL SIGNAL) button to store the setting in memory, exit the SET-UP MODE, and return to normal operation.

A preset is activated, or "called-up", from memory, by pushing the appropriate PRESET button (in either a momentary or latching mode). Prior to activating the circuits specified by the preset memory, the microprocessor first stores the existing button settings in its temporary buffer memory, then, when the preset is released, the microprocessor restores the previous button settings.

RELAYS programming function (See Figure 3-1)

The RELAYS function enables any of the six programmable relays to be assigned to- and be activated by- any one or combination of the twenty-four selection buttons {4} and/or the SPEAKER ON {9} and MICROPHONE ON {10} buttons. These relay contacts are accessible on the rear panel and can be used for any audio or low-current control switching requirements. An example might be assigning a relay to turn off a monitor loudspeaker in a control room.

To program a button to activate a relay:

- 1) Enter the "SET-UP MODE",
- 2) Choose RELAYS by pushing the RELAY (PRESET 2) button,
- 3) Choose which of six relays you are programming by pushing RELAY 1 through RELAY 6 (LISTEN buttons for channels 1 through 6 respectively),
- 4) Push the buttons that will activate the chosen relay,
- 5) Push RELAYS (PRESET 2) to store the setting and do further programming, or push the SET-UP MODE (CALL SIGNAL) button to store the setting in memory, exit SET-UP MODE and return to normal operation.

CALL LIGHTS programming function (See Figure 3-1)

The CALL DISABLE (call signal receive disable) programming function is only enabled if the Model 802 is equipped with a Call Signal option. In a multiple Master Station system, all 802's may not want to receive incoming CALL signals from all channels. Individual 802's may be selectively programmed to accept CALL signals only from specific channels. For example, in a television studio, the audio booth's 802 would be programmed to accept signals on the Audio channel only while other 802's would be programmed to reject any signals on the Audio channel. Only the receive function is programmable. The "send" or outgoing signal is always enabled on all channels equipped with the Signal option.

To program the CALL DISABLE programming function to a button or buttons:

- 1) Enter the "SET-UP MODE",
- 2) Push the CALL DISABLE (PRESET 3) button,
- 3) Push one or more buttons that you wish to disable the CALL function,
- 4) Push the CALL DISABLE (PRESET 3) button again to store the setting and to do further programming, or push the SET-UP MODE (CALL SIGNAL) button to exit SET-UP MODE.

LATCH DISABLE programming function (See Figure 3-1)

The LATCH DISABLE programming function allows the latching action of any dual-action button to be disabled. This means a button can be programmed to function as a momentary action button only. A logical application would be when a TALK button is programmed to key a two-way radio transmitter. In this application, when the transmitter should not be keyed continuously on, disabling the latch action allows momentary keying only.

To program the LATCH DISABLE programming function to a button:

- 1) Enter the "SET-UP MODE",
- 2) Push the LATCH DISABLE (PRESET 4) button,
- 3) Push one or more buttons that you wish to disable the latch function,
- 4) Push the LATCH DISABLE (PRESET 4) button again to store the setting and do further programming, or push the SET-UP MODE (CALL SIGNAL) button to store the setting(s), exit SET-UP MODE and return to normal operation.

PRESET EXCLUDE programming function (See Figure 3-1)

The PRESET EXCLUDE programming function allows one or more of the twenty-four selection buttons to be excluded from the PRESET function. This means that the excluded button cannot be programmed to be part of a preset. As such, it will no longer be considered a valid button during PRESET programming, and it will not change state when a preset is selected. The PRESET EXCLUDE function, therefore, may be used to avoid turning off an important circuit by activation of a preset.

To program a button using the PRESET EXCLUDE programming function:

- 1) Enter the "SET-UP MODE",
- 2) Push the PRESET EXCLUDE (SPEAKER ON) button,
- 3) Push one or more buttons that you wish to exclude from being preset.
- 4) Push the PRESET EXCLUDE button again to store that setting and do further programming, or push the SET-UP MODE (CALL SIGNAL) button to store the setting, exit SET-UP MODE and return to normal operation.

BUFFER RECALL function

The BUFFER RECALL is used in conjunction with the PRESETS function as follows:

- 1) Upon entering the SET-UP MODE, the microprocessor first stores the existing front panel settings in a temporary "buffer" memory,
- 2) After selecting the PRESETS programming function and selecting PRESET 1, 2, 3, or 4, push BUFFER RECALL to transfer the pre-SET-UP front panel settings from the temporary buffer memory into the preset you are programming. You can store that setting in the normal manner as explained in the preset programming section.

SPECIAL PURPOSE programming function

The SPECIAL PURPOSE programming function enables 24 additional functions, of which two are assigned in Firmware Version 4.3:

Row/Column	Function
1/1	BUTTON DISABLE ASSIGN
1/2	INSTANT MIC ON ASSIGN

The BUTTON DISABLE ASSIGN function allows any of the 24 Talk/Listen or 4 Preset buttons to be locked ON or OFF. For example, a Talk button and an assigned relay may be holding a telephone line on during a particular operation, and locking the button will prevent accidentally disconnecting the phone line. Or, in another example, access to a given channel may be restricted at some master stations by locking the talk and listen buttons for that channel in the OFF state.

To program the BUTTON DISABLE function to a button:

- 1) Enter the "SET-UP MODE",
- 2) Push the SPECIAL FUNCTION (MIC ON) button,
- 3) Of the buttons now flashing, push the button at Row 1, Column 1.
- 4) Push one or more buttons that you wish to disable.
- 4) Push the SPECIAL FUNCTION button again to store the setting and do further programming, or push the SET-UP MODE (CALL SIGNAL) button to store the setting(s), exit SET-UP MODE and return to normal operation.

The INSTANT MIC ON ASSIGN function allows a Talk button to automatically key the Microphone ON/OFF Switch. For example, a Talk button and its associated channel could be made into a Page or Stage Announce function. The default states for the INSTANT MIC ON ASSIGN are as follows: The regular 12 channels of intercom Talk buttons are not INSTANT MIC ON; the IFB, Squawk and Iso functions are normally INSTANT MIC ON.

To program the INSTANT MIC ON (or not ON) function to a button:

- 1) Enter the "SET-UP MODE",
- 2) Push the SPECIAL FUNCTION (MIC ON) button,
- 3) Of the buttons now flashing, push the button at Row 1, Column 2.
- 4) Push one or more buttons that you wish to enable or disable.
- 4) Push the SPECIAL FUNCTION button again to store the setting and do further programming, or push the SET-UP MODE (CALL SIGNAL) button to store the setting(s), exit SET-UP MODE and return to normal operation.

ADDENDA

SUBJECT: 802 UPDATES FOR COMPATIBILITY WITH MODELS VCP-6A1 VCP-12A

DATE: 10-25-84

PAGE: 1 OF 2

THE UPDATE FROM THE VCP-6/VCP-12 OPTIONS TO THE VCP-6A/VCP-12A 802 ISO OPTIONS CONSISTS OF THE ADDITION OF A "GLOBAL RESET" FUNCTION. THIS GLOBAL RESET FUNCTION APPEARS ON THE 802 FRONT PANEL BUTTON NORMALLY USED AS PRESET 4 (802 UNITS WITH THE UPDATED VCP-6A/VCP-12A ISO OPTIONS HAVE ONLY 3 PRESET BUTTONS AVAILABLE). WHEN THE GLOBAL RESET BUTTON IS PUSHED, ALL ISO BUTTONS ON ANY 802'S, VCP-6A'S, AND/OR VCP-12A'S IN THE SYSTEM WILL RESET. 802 UNITS, WITH ISO OPTIONS, WHICH HAVE NOT BEEN UPDATED TO INCLUDE GLOBAL RESET WILL STILL WORK WITH A VCP-6A/VCP-12A SYSTEM, BUT THE 802 WILL NOT BE ABLE TO GENERATE OR RECEIVE THE GLOBAL RESET COMMAND.


IF AN 802 UNIT, WITH ANY ISO OPTIONS (H0, H1, H5), DOES NOT APPEAR TO HAVE THE GLOBAL RESET FUNCTION, REMOVE THE BOTTOM COVER AND CHECK THE REVISION LETTER ON THE MOTHER BOARD (AW3000-1). 802 UNITS WITH MOTHER BOARDS HAVING REVISION LETTERS OF "G" OR LESS HAVE NOT BEEN UPDATED.

TO UPDATE THE 802 UNIT, WITH AN ISO OPTION, FOR GLOBAL RESET:

- 1) ADD THE FOLLOWING TO THE CIRCUIT (BOTTOM) SIDE OF THE MOTHER BOARD (REFER TO SHEET 2):
 - A) ADD D64 (DIODE, INTERNATIONAL RECTIFIER #11DQ03, RTS #1601-0001-00) BETWEEN J53 PIN 9 (ANODE) AND J223 PIN 6 (CATHODE).
 - B) ADD D63 (DIODE, INTERNATIONAL RECTIFIER #11DQ03, RTS #1601-0001-00) BETWEEN J53 PIN 10 (ANODE) AND J223 PIN 9 (CATHODE).
 - C) ADD A JUMPER WIRE BETWEEN J53 PIN 10 AND J54 PIN 9.
- 2) IN UNITS SHIPPED PRIOR TO 10-29-84 ONLY, INSTALL NEW FIRMWARE (V.4.2 AND UP) IN THE MEMORY PROM POSITIONS U12, U13, AND U14 OF THE CPU BOARD (AW3000-5). THE CPU BOARD CAN BE ACCESSED BY REMOVING THE 802 TOP COVER.

NOTES:

1. SOLDER JUMPER WIRES TO THE CATHODE LEADS OF BOTH D63 AND D64. INSULATE EACH DIODE, AND ITS JUMPER WIRE SOLDER CONNECTION, WITH SHRINK TUBING.
2. JUMPER WIRES SHOULD BE #24 OR #22 AWG.



DETAIL: VCP-6A UPDATES TO THE 802 MOTHER BOARD,
AW 3000-1 (CIRCUIT SIDE SHOWN)




Fig 3-6-2 / pg 55
2 @

Fig 3-9-6 / pg 92
1 @

MODEL 802
ASSEMBLY DIAGRAM
MOTHER BOARD
AS 3000-1
-1

Fig 3-4-6 / pg 42
1 @

Fig. 3-10-1 / pg 94
1 @

MODEL 802
 ASSEMBLY DIAGRAM
 CPU BOARD
 AS 3000-5
 -2






Fig. 3-10.1
 10

MODEL 802
 ASSEMBLY DIAGRAM
 PIO BOARD
 AS 3000-4
 -3




- NOTES: UNLESS OTHERWISE SPECIFIED
1. FOR PIO #1 BOARD: INSTALL W401,
 2. " " #2 " : " W402,
 ; CHANGE R406 TO 1K PACKAGE.
 3. " " #3 " : " W403.
 4. INSTALL ONLY ONE JUMPER PER BOARD
 ("W401 THRU W404")

Fig. 3-10-1
 1 @




MODEL 802
 ASSEMBLY DIAGRAM
 ADJUSTMENT BOARD
 AS3000-7
 - 4



~~BOZ OP~~
 MODEL 802
 ASSEMBLY DIAGRAM
 SWITCH BOARD
 AS 3000-9
 -5

TALK/SQUAWK OPTION BD
AS3000-3 REV A
RTS SYSTEMS




* REF DES CODE
X3XX OMITTED
EX: U01 U301

REV B AND C
ALSO APPLICABLE


793-6-2/1955
20


802 OPTIONAL
ASSEMBLY DIAGRAM
TALK/SQUAWK BOARD
AS3000-3 - 6

802 OPTIONAL
 ASSEMBLY DIAGRAM
 WIRE BOARD
 SECOND GENERATION
 AS 3000-6-1






802 OPTIONAL
ASSEMBLY DIAGRAM
CALL LIGHT
AS 3000-18 - 8





802 OPTIONAL
 IFB/VCP BOARD
 SECOND GENERATION
 ASSEMBLY DIAGRAM
 AS3000-2 -9

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
A		REVISED AND REDRAWN	9-24-82	
B		UPDATED	10-21-82	
C		REVISED PER ECO #1114	10-13-83	
D		CHANGED NOTE 1 WAS -C469 ECO # 1907	5-1-87	




2.C401-C440 ARE .01μF/50V MONO.CERAMIC CAPACITORS FOR DEBOUNCING.
 1.C441-C460 ARE .1μF/50V MONO.CERAMIC CAPACITORS USED TO BYPASS EACH I.C.
 NOTES:(UNLESS OTHERWISE SPECIFIED)

USED ON THIS PAGE: C401-C440,
 J401-J415, R401-R411, U401-U428

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XX ± .XXX ±		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
APPROVALS		DATE		SCHEMATIC DIAGRAM	
DRAWN S. DUEBBER		9-24-82		MASTER STATION MODEL 802	
CHECKED		ISSUED		SIZE FSCM NO. DWG. NO. REV. D 00572 SD 3000 D	
NEXT ASSY		USED ON		SCALE SHEET	
APPLICATION		DO NOT SCALE DRAWING			

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
A	UPDATED		12-9-82	
B	REVISED PER ECO# 2391		1-23-84	




⚠ CHIME CIRCUITRY IS ON THE CPU IN THE 802A.

NOTES:

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XX ± .XXX ±		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	SCHEMATIC DIAGRAM MASTER STATION, MODELS 802 & 802A ANALOG BLOCK	
FINISH		DRAWN R. PEKSON	7-26-84	REV. B	
NEXT ASSY	USED ON	ISSUED		SIZE D	FSCM NO. 60572
APPLICATION		DO NOT SCALE DRAWING		SCALE	DWG. NO. SD3000
				REV. B	
				SHEET 1 OF 26	


REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED & REDRAWN	10-2-82	
	B	UPDATED	12-9-82	SLH
	C	PER ECO #2391	2-10-89	



1. SEE PIO LISTING FOR ALL PIO INPUT/OUTPUT CONNECTIONS.
 NOTES (UNLESS OTHERWISE SPECIFIED)

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS .XX ± DECIMALS .XXX ± ANGLES ±		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	SCHEMATIC DIAGRAM	
FINISH		S. DUEBBER 10/1/82		DIGITAL BLOCK MODEL 802, 802A	
NEXT ASSY		ISSUED		MASTER STATION	
USED ON		SCALE		SIZE D	REV. C
APPLICATION		DO NOT SCALE DRAWING		FSCM NO. 60572	DWG. NO. SD 3000
				SHEET 3 OF 26	

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED	9-27-82	
	B	REVISED	10-1-82	
	C	UPDATED	10-28-82	
	D	C14 WAS 10/10	11-12-82	
	E	CATHODE D16 WAS CONNECTED TO C8 (-). CATHODE D17 WAS CONNECTED TO C18 (-).	12-28-82	
	F	REVISED PER ECO # 958	5-16-83	
	G	R43 WAS 220K PER ECO 990	7-7-83	
	H	REV PER ECO 991	7-12-83	
	J	REVISED PER ECO 154B	11-18-85	
	K	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES.	7-10-86	
	L	PER ECO # 2372	1-3-89	
	M	PER ECO # 2391	1-10-89	



USED ON THIS PAGE: C1-C39, C91, C99, D1-D7, D16, D17, J1, J2, J6, J10, J11, J100, R1-R20, R22-R47, R120-R123, R746, R747, U1-U5, T1, T2, Q1, Q2, TB9, TB10, TB13, TB14, E1-E18, E30

NOT USED ON THIS PAGE: C40-C90, D8-D15, R21, R48-R119

4. —S— = SCHOTTKY DIODES, VF = 0.1 TO 0.3V.
 3. CUTTABLE TRACES (USED FOR OPTIONS) ARE SHOWN ://.
 2. CAP. VALUES ARE SHOWN: MICROFARADS/VOLTS.
 1. ALL RESISTORS ARE CARBON FILM, 1/4 WATT, ±5%.


NOTES: UNLESS OTHERWISE SPECIFIED

- ① OMIT R44A WHEN CHIME OPTION IS NOT USED.
- ② USE ON TYPE B HDST MIC ELECTRET OPTION ONLY.
- ③ FOR DYNAMIC PANEL MIC; REMOVE R3, CHANGE VALUE OF C3 TO 10/10

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS .XX ± DECIMALS .XXX ± ANGLES °		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS		DATE	
FINISH		DRAWN R. PEKSON		7-30-84	
NEXT ASSY		CHECKED			
USED ON		ISSUED		SIZE FSCM NO. DWG. NO. REV.	
APPLICATION		DO NOT SCALE DRAWING		D 60572 SD 3000 M	
		SCALE		SHEET 4 OF 26	

TO TALK
SELECT SWITCHES
TO: U210 -12
-2
-5
-5
U211 -12
-2
-5

TALK OPTION BOARD
SQUAWK OPTION BOARD



USED ON THIS PAGE: C40-C91, D8, D9, J2-J5, J7, J8, J11, J13, J50, J100, J223, Q3, Q4, R48-R104, R109, R292, R153, T3, T4, TB9, TB15, E20-E23


NOT USED ON THIS PAGE: R100, R105-R108

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
A	REVISED		9-27-82	
B	REVISED		10-2-82	
C	UPDATED		10-28-82	
D	UPDATED		11-12-82	
E	REV PER ECO # 790		2-14-83	
F	REV PER ECO # 956 & 957		4-28-83	
G	REV PER ECO # 954 & 955		5-16-83	
H	REV PER ECO # 1017		6-14-83	
J	REV PER ECO # 1130		11-9-80	
K	ADDED NOTE (8)		12-2-83	
L	REVISED PER ECO 1284		9-7-84	
M	REVISED PER ECO 1321		11-11-84	
N	REVISED PER ECO 1388		1-15-84	
P	REVISED PER ECO 1408		1-21-85	
R	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES.		7-10-86	
S	C66,67 WERE .2/50 MONO. REF ECO 1453		8-8-86	
T	ADDED R108 PER ECO 1938	6M	9-30-87	
U	R153 DESTINATION, R165 WAS 22K	ECO#2117	4-1-88	
V	ADDED C40	PER ECO # 2167	4-1-88	
W	PER ECO # 2372		1-3-89	
X	PER ECO # 2391		2-10-89	

- (10) THESE COMPONENTS ARE PART OF AN ALTERNATE ISG CIRCUIT, USED ONLY WHEN CHANNEL 13 LISTEN IS USED IN 4-WIRE MODE.
 - (9) OPTIONAL PARTS C47, C48, R58, R59 MAY BE ADDED TO ADJUST HEADPHONE AMPLIFIER GAIN.
 - (8) THESE PARTS OPTIONAL. (D8, D9)
 - (7) LIGHT DEPENDENT RESISTOR PN CLM6000 OR VTLS2.
 - 6. 4053 CONFIGURATION IS AS SHOWN BELOW.
-
- 5 SUPPLY VOLTAGE
 - 4 OUTPUT
 - 3 GROUND
 - 2 INVERTING INPUT
 - 1 NON-INVERTING INPUT
- 4. = SCHOTTKY DIODE, VF = 0.1 TO 0.3V.
 - 3. CUTTABLE TRACES (USED FOR OPTIONS) ARE SHOWN: .
 - 2. CAP. VALUES ARE SHOWN: MICROFARADS/VOLTS.
 - 1. ALL RESISTORS ARE CARBON FILM, 1/4 WATT, ±5%.
- NOTES: (UNLESS OTHERWISE SPECIFIED)

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES XX ± .XX ±		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
APPROVALS		DATE		SCHEMATIC DIAGRAM	
DRAWN R. PEKSON		8-2-84		MOTHERBOARD HEADPHONE AND	
CHECKED				SPEAKER AMP	
ISSUED				MASTER STATION, MODEL 802, 802A	
NEXT ASSY		USED ON		SIZE FSCM NO. DWG. NO.	
APPLICATION		DO NOT SCALE DRAWING		D 60572 SD3000	
SCALE				REV. X	
				SHEET 5 OF 26	

TO J615 MOTHERBOARD SHEET 6 ZONE D4



AUX INPUTS
4X1H
4X1L
4X2H
4X2L

USED ON THIS PAGE: C701-C719, J701-J706, R701-R756, R761-R764, S701-S709, S736, S741-S756, S761-S776, U701-U706, DS700-DS703

NOT USED ON THIS PAGE: R757-R759, S710-S720, S737-S740, S757-S760

(SHEET 5 ZONE D4) TO J4 AT MOTHER BOARD

DIP SWITCHES

S701, NOT USED	1	1
S702, NOT USED	2	2
S703, IFB ON/OFF	3	3
S704, IFB 8/4 OR 150 12/6	4	4
S705, PRESET EXCLUSIVE	5	5
S706, TLK/LIST PAIR EXCL	6	6
S707, COLD START	7	7
S708, SET-UP DISABLE	8	8
	9	9
	10	10

J705 J706

1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10

J701 J702

1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10

J703 J704 P6 J6 (SHEET 4) ZONE D7

1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10

J706

1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10


REVISIONS

ZONE	REV.	DESCRIPTION	DATE	APPROVED
C	REVISED		10-28-82	
D	UPDATED		11-23-82	
E	J706 WAS A MOLEX CONN; ADDED J706 PIN4, J701 PINS 10,7,9,8 WERE 7,10,8,9		12-29-82	
F	REVISED PER ECO #832		4-6-83	
G	REVISED PER ECO #939		4-11-83	
H	REV PER ECO #956 & 957		4-28-83	
J	REV PER ECO #955		5-16-83	
K	REV PER ECO #997		6-13-83	
L	REVISED PER ECO 1474		7-9-85	
M	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO #1432 FOR COMPLETE LIST OF ADDITIONS / CHANGES.		7-10-86	
N	CHNG DIP SW FUNCTION CALLOUTS		9/12/86	
P	PER ECO #2391		2-10-89	

- 6 ALTERNATE VALUE: 100K.
 5. U705, U706 ARE NE5532N.
 4. U701-U704 ARE MC3403N.
 3. R737-R742 = 47K SIPS.
 2. R760 = 220Ω SIP.
 1. RESISTORS ARE 1/4W CARBON FILM ± 5%. CAPACITORS VALUES ARE MICROFARADS/VOLTS.
- NOTES: UNLESS OTHERWISE SPECIFIED.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE FRACTIONS DECIMALS ANGLES .XX ± .XXX ±		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS		DATE	
FINISH		DRAWN R. PEKSON		8-1-84	
NEXT ASSY		ISSUED		SIZE FSCM NO. DWG. NO. REV	
USED ON		DO NOT SCALE DRAWING		D 60572 SD3000 P	
APPLICATION		SCALE		SHEET 7 OF 26	





REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED & REDRAWN	10-12-82	
	B	UPDATED	10-28-82	
	C	UPDATED	12-9-82	
	D	UPDATED PER ECO 931	4-8-83	
	E	REV PER ECO # 954	5-16-83	
	F	REV PER ECO # 997	6-13-83	
	G	REV PER ECO # 1033	6-24-83	
	H	REVISED PER ECO 1581	1-27-86	
	J	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES. CHANGED PIN NOS 1&2 TO 13 & 12 ON U212.	7-10-86	
	K	PER ECO # 2372	1-3-89	
	L	PER ECO # 2391	2-10-89	



- 10 R290 IS PART OF AN ALTERNATE ISO CIRCUIT, USED ONLY WHEN CHANNEL 13 IS USED IN 4-WIRE MODE.
- TRANSFORMERS ARE 600:600, LM9003.
 - ALB AUDIO LISTEN BALANCE AND ALF AUDIO LISTEN FEED GO TO LISTEN SWITCHING AREA OF MOTHERBOARD 5601-5612, PAGE 6.
 - LTX-13, 14, 15 ARE SPARE INPUTS.
 - LTX-1-LTX-6 CALLOUTS CONNECT TO CALL LIGHT P.C.B., TRANSMITTER CHANNELS 1-6, SHEET 18.
 - U201-U209, U214 ARE NE532N.
 - |— = SCHOTTKY DIODE, VF = 0.1 TO 0.3V
 - CUTTABLE TRACES (USED FOR OPTIONS) ARE SHOWN: —/—
 - CAP VALUES ARE SHOWN: MICROFARADS/VOLTS.
 - ALL RESISTORS ARE CARBON FILM, 1/4 WATT, ± 5%
- NOTES: UNLESS OTHERWISE SPECIFIED

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES .XX ± .XXX ±		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS		DATE	
FINISH		DRAWN		1-27-86	
NEXT ASSY		CHECKED		ISSUED	
USED ON		ISSUED		SCALE	
APPLICATION		DO NOT SCALE DRAWING		SIZE FSCM NO. DWG. NO. REV.	
		D		60572 SD3000 L	
				SHEET 8 OF 26	

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REDRAWN	10-15-82	
	B	REVISED & REDRAWN	2/14/82	SLH
	C	REVISED PER ECO # 919	3.MAR82	A-7-83
	D	REVISED PER ECO # 1030	6.MAR82	6-24-83
	E	REVISED PER ECO 1397		1-18-85
	F	ADDED NOTE 4. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES		7-10-85
	G	DELETED W/2 ECO # 2133		2-16-88
	H	PER ECO # 2391		2-10-89



4. SEE SHEET 10 FOR DESTINATION OF CONNECTORS J300, J310, J316, J317, J318. SEE SHEET 21 FOR CONNECTORS J300, J303, J304, J305, J308, J309, J310, J318.

▲ R371 & R372 USED ON SQUAWK OPTION P.C.B.#2 (SQUAWK 7-10) ONLY (USED FOR MORE THAN 6 CHANNELS OF SQUAWK); FOR TERMINATION OF UNUSED BILATERAL CURRENT SOURCES.

2. D311-D316, D321-D326 ARE 1AMP, 30V SCHOTTKY DIODES; EX. INT. RECT. PN 11DQ03.

▲ FOR SQUAWK OPTION, SET SQUAWK LISTEN CH. SELECT SWITCH (S309) AS DESCRIBED: TALK/SQUAWK P.C.B.#1 CONTAINS LISTEN TAPS 1-6; TALK/SQUAWK P.C.B.#2 CONTAINS LISTEN TAPS 7-10. TO ASSIGN SQUAWK POSITION, SET S309 ON THE P.C.B. THAT CONTAINS THE PROPER LISTEN TAP, TO THAT LISTEN TAP SET S309 ON THE P.C.B. THAT DOES NOT HAVE THE DESIRED LISTEN TAP TO SWITCH POSITION 7, 8, 9, OR 10 (NOT CONNECTED). FOR EXAMPLE: FOR SQUAWK 8, S309 ON P.C.B.#1 IS SET TO POSITION 7, 8, 9, OR 10. S309 ON P.C.B.#2 IS SET TO POSITION 2 (LT8)




NOTES: UNLESS OTHERWISE SPECIFIED

USED ON THIS PAGE: C310-C316, C320-C326, C331-C336, C341-C346, C351-C356, C361-C367, D311-D316, D321-D326, E301-E307, J300A, J300B, J303, J304A, J304B, J305, J306, J308, J309, J310, J316-J318, R310-R370, T311, T321, T331, T341, T351, T361, U301-U308.

CONTRACT NO.		SERIES 800		RTS SYSTEMS		BURBANK, CALIFORNIA	
MATERIAL		APPROVALS		DATE		SCHEMATIC DIAGRAM-MASTER STATION - MODEL 802, 802A, TALK/SQUAWK OPTION BD	
FINISH		DRAWN		CHECKED		ISSUED	
NEXT ASSY		USED ON		SCALE		DWG. NO.	
APPLICATION		DO NOT SCALE DRAWING		SCALE		REV.	
		AS3000-3		802A		D 60572	
						SD 3000	
						H	
						SHEET 9 OF 26	

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	C	REVISED & REDRAWN PER ECO # 919	4-7-83	
	D	ADDED NOTE 2. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES.	7-10-86	
	E	DELETED W/ ECO # 2133	2-17-88	
	F	PER ECO # 2391	2-10-89	


(REAR PANEL)
LINE CONNECTOR
JIOT SHEET 20



2. SEE ALSO SHEET 21 FOR SQUAWK CONNECTIONS.
1. N.C. = NO CONNECTION
NOTE: (UNLESS OTHERWISE SPECIFIED)

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XXX ± .XXX ±	CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA		
	APPROVALS	DATE	SCHEMATIC DIAGRAM - TALK OPTION (TALK CHANNELS 7-12) INTERCONNECT		
	DRAWN B.MAEZ	4-7-83	SIZE D	FSCM NO. 60572	DWG. NO. SD3000
	CHECKED		SCALE		REV. F
ISSUED				SHEET 10 of 26	
DO NOT SCALE DRAWING					

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	UPDATED	10-28-82	
	B	REV. PER ECO # 997	6-14-83	B. MACE
	C	ADDED INTERSHEET REFERENCE FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES.	7-10-86	
	D	PER ECO # 2391	2-10-89	



TALK 1	TALK 2	TALK 3	TALK 4	TALK 5	TALK 6	TALK 7	TALK 8	TALK 9	TALK 10	TALK 11	TALK 12
DS 901	DS 902	DS 903	DS 904	DS 905	DS 906	DS 907	DS 908	DS 909	DS 910	DS 911	DS 912
S901	S902	S903	S904	S905	S906	S907	S908	S909	S910	S911	S912
LISTEN 1	LISTEN 2	LISTEN 3	LISTEN 4	LISTEN 5	LISTEN 6	LISTEN 7	LISTEN 8	LISTEN 9	LISTEN 10	LISTEN 11	LISTEN 12
DS 913	DS 914	DS 915	DS 916	DS 917	DS 918	DS 919	DS 920	DS 921	DS 922	DS 923	DS 924
S913	S914	S915	S916	S917	S918	S919	S920	S921	S922	S923	S924
PRESET 1	PRESET 2	PRESET 3	PRESET 4	CALL	PANEL MIC	SPKR ON	MIC ON				
DS 925	DS 926	DS 927	DS 928	DS 929	DS 930	DS 931	DS 932				
S925	S926	S927	S928	S929	S930	S931	S932				

LAMP AND SWITCH NUMBERING : VIEW FROM SWITCH SIDE OF SWITCHBOARD

J901 TO J406
 J902 TO J407
 J903 TO J408
 J904 TO J409
 J905 TO J401
 J906 TO J402
 J907 TO J403
 J908 TO J404


2. J901-J908 CONNECT TO PIO' BD #1, SEE SHEET 12.
 1. ALL DIODES ARE IN4004.
 UNLESS OTHERWISE SPECIFIED.

NOTES :

USED ON THIS PAGE : D901-D938, DS901-DS932, J910
 S901-S932, J901-J908

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS .XX ± . DECIMALS .XXX ± . ANGLES ±		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL	APPROVALS	DATE	SCHEMATIC DIAGRAM MASTER STATION, MODEL 802,802A (SWITCHBOARD)		
FINISH	S. DUEBBER	5-8-82			
NEXT ASSY	CHECKED				
USED ON	ISSUED		SIZE	FSCM NO. D 60572	DWG. NO. SD 3000
APPLICATION	DO NOT SCALE DRAWING		SCALE		REV D
					SHEET 11 OF 26

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED AND REDRAWN	9-24-82	
	B	UPDATED	10-21-82	
	C	CHANGED 74C14 TO 74C04	12-9-82	
	D	REV PER ECO# 997	6-14-83	
	E	REV PER ECO# 1114	10-13-83	
	F	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES	7-10-86	
	G	CHANGED NOTE 1 WAS -C469 ECO 1907	5-1-87	
	H	PER ECO# 2391	2-10-89	



- [MSE] J2-2 DO0
- [PME] J2-3 DO1
- [HME] J2-4 DO2
- [SES] J2-5 DO3
- [SPE] J2-6 DO4
- [SPD] J2-7 DO5
- ISO TALK DO6
- ISO LISTEN DO7


- STATUS LED
- # 1 DO0
- # 2 DO1
- # 3 DO2
- # 4 DO3
- # 5 DO4
- # 6 DO5
- # 7 DO6
- # 8 DO7

USED ON THIS PAGE: C401-C440, J401-J415, R401-R411, U401-U428

2. C401-C440 ARE .01μF/50V MONO. CERAMIC CAPACITORS FOR DEBOUNCING.
 1. C441-C460 ARE .1μF/50V MONO. CERAMIC CAPACITORS USED TO BYPASS EACH I.C.
 NOTES (UNLESS OTHERWISE SPECIFIED)

CONTRACT NO.		SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
APPROVALS		DATE		SCHEMATIC DIAGRAM	
DRAWN S. DUEBBER		9-24-82		MASTER STATION MODEL 802, 802A,	
CHECKED				PIO #1, I/O BOARD	
ISSUED		DWG. NO.		REV.	
SIZE		D 60572		SD 3000 H	
SCALE				SHEET 12 OF 26	

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED AND REDRAWN	9-24-82	
	B	UPDATED	10-21-82	
	C	CHANGED R406A-H, WAS 1M Ω	11-23-82	
	D	CHANGED 74C14 TO 74C04	12-9-82	
	E	REN PER ECO# 997	6-14-83	
	F	REV PER ECO# 1114	10-13-83	
	G	ADDED KEYS TO PINS 6 & 9 OF J411 GM	10-9-84	
	H	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES	7-10-86	
	J	CHNG MOTHERBD DIP SW FUNCTION CALLOUTS RB	9-12-86	
	K	REV. J401 & J402 PIN FUNCTION CALLOUTS	9-26-86	
	L	CHANGED NOTE 1 WAS -C469 ECO 1907	5-1-87	
	M	PER ECO# 2391	2-10-89	






USED ON THIS PAGE: C401-C440, J401-J415, R401-R411, U401-U428

2.C401-C440 ARE .01 μ F/50V MONO.CERAMIC CAPACITORS FOR DEBOUNCING.
1.C441-C460 ARE .1 μ F/50V MONO.CERAMIC CAPACITORS USED TO BYPASS EACH I.C.
NOTES:(UNLESS OTHERWISE SPECIFIED)

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES .XX ± .XXX ±		CONTRACT NO. SERIES 800	RTS SYSTEMS BURLINGAME, CALIFORNIA	
MATERIAL	APPROVALS	DATE	SCHEMATIC DIAGRAM	
AS3000-4 80Z	S. DIEBBER	9-24-82	MASTER STATION MODEL 802, 802A	
FINISH	CHECKED		PIO #2 I/O BOARD	
NEXT ASBY	ISSUED		SIZE FSCM NO.	DWG. NO.
APPLICATION	DO NOT SCALE DRAWING		D 6057Z	SD 3000
			SCALE	SHEET 13 OF 26

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED AND REDRAWN	9-24-82	
	B	UPDATED	10-21-82	
	C	CHANGED 74C14 TO 74C04	12-9-82	
	D	REV PER ECO # 997		
	E	REV PER ECO # 1114	10-13-83	LB
	F	ADDED GLOBAL RE-KEY ON PIN 9, J405	11-9-84	
	G	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES. ADDED NOTES 3 & 4.	7-10-86	
	H	CHANGED NOTE 1 WAS -C469 ECO 1907	5-1-87	
	J	PER ECO # 2391	2-10-89	




△ TO CALL LIGHT R.C.B. #2 SHEET 18.
 △ TO CALL LIGHT R.C.B. #1 SHEET 18.
 2. C401-C440 ARE .01μF/50V MONO. CERAMIC CAPACITORS FOR DEBOUNCING.
 1. C441-C460 ARE .1μF/50V MONO. CERAMIC CAPACITORS USED TO BYPASS EACH I.C.
 NOTES: (UNLESS OTHERWISE SPECIFIED)

USED ON THIS PAGE: C401-C440,
 J401-J415, R401-R411, U401-U428

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
FRACTIONS	DECIMALS	ANGLES	APPROVALS	DATE	
			S. DUEBBER	9-24-82	
MATERIAL	AS3000-4	802	CHECKED		
FINISH	NEXT ASSY	USED ON	ISSUED		
APPLICATION	DO NOT SCALE DRAWING		SCALE		
			SIZE	FBCM NO.	REV
			D	60572	J
			DWG. NO.	SD 3000	
			SCALE		SHEET 14 OF 26

ZONE	REV.	DESCRIPTION	DATE	APPROVED
A	REVISED & REDRAWN		10-6-82	
B	UPDATED		10-28-82	
C	DELETE D2,U10,U24		11-15-82	
D	NOTE 5 DELETED AT U14 ONLY; ADDED R14A-I, U16 WAS 27C16; ADDED C17,C18; C6 WAS 150/1/5V TANT.		11-23-82	
E	UPDATED		12-29-82	
F	D3 WAS 1N5018	MV	8-3-83	
G	REVISED J6 PER ECO 1105	DM	9-26-83	
H	REVISED D1 PER ECO 1340	WD	10-25-84	
J	REVISED PER ECO 1408		1-21-85	
K	CORRECTED VALUE @ C3 PER ECO 1577	MV	1-15-86	
L	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES		7-10-86	
M	REVISED PER ECO # 1936		7-15-87	
N	REVISED PER ECO # 2391		1-23-89	



Y1 - 4.0MHz	NO. OF PINS	PIN # +5V	PIN # GND
U2 - NSC800N	40	40	20
U3 - 74PC00	14	14	7
U4 - 74PC04	14	14	7
U5-U7 - 82PC08	20	20	10
U8 - 82PC12	24	24	12
U9 - U11 - 74PC138	16	16	8
U12-U15 - 27C16	24	24	12
U19,U20 - CD4040	16	14	8
U23 - 74PC02	14	14	7
U16 - 6116	24	24	12

6. THIS CPU SCHEMATIC IS USED ONLY FOR THE MODEL 802. SEE SD5336 FOR THE MODEL 802A CPU.

5 FOR FUTURE USE

4. C7-C16 ARE 0.1/50V MONO CAPS.

3. WHERE PROMS ARE USED JUMPER PIN Z1 TO +5V

2. WHERE RAMS ARE USED JUMPER PIN Z1 TO WR

1. INITIAL BOARD POPULATION WILL BE 2 PROMS - 27C16
1 RAM - 6116
2 SPARE

NOTES: UNLESS OTHERWISE SPECIFIED

A15	A14	A13	A12	A11				
0	0	0	0	0	0000H	PROM 1		
1	0	0	0	0	2048	0800H	PROM 2	
1	0	0	0	1	4096	1000H	PROM 3	
1	1	1	1	1	6144	1800H	PROM 4	
1	0	0	0	1	8192	2000H	MEM -	
1	0	1	0	1	10240	2800H	X	
1	1	0	0	1	12288	3000H	X	
1	1	1	1	1	14336	3800H	DEV	


LAST USED: C18,D8,J8,Q3,R14,U25

NOT USED: D2,D6,U1,U10,U17,U18, U21,U22,U24

IN/OUT	PIN	PERIOD
Q0	10	0.50 mA
Q1	9	1.00
Q2	7	2.05
Q3	6	4.10
Q4	5	8.20
Q5	3	16.40
Q6	2	32.80
Q7	4	65.60
Q8	13	131.20
Q9	12	261.00
Q10	14	523.00
Q11	15	1046.00
Q12	1	2192.00

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES .XX ± .XXX ±		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS		DATE	
FINISH		DRAWN S.DUEBBER		10-6-82	
NEXT ASSY		CHECKED		ISSUED	
USED ON		SCALE		DWG. NO. SD 3000	
APPLICATION		DO NOT SCALE DRAWING		SHEET 15 OF 26	

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED	10-21-82	
	B	UPDATED PER ECO 931	4-11-83	
	C	UPDATED PER ECO 955	5-16-83	
	D	REVISED PER ECO 947	6-14-83	
	E	REVISED PER ECO 1385 GM	2-8-85	
	F	REVISED PER ECO 1474 GM	7-9-85	
	H	REVISED PER ECO 1581	1-27-86	
	J	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES	7-10-86	
	K	CHNG DIP SW FUNCTION CALLOUTS	9-12-86	RB
	L	REVISED PER ECO # 2214		
	M	PER ECO # 2391	2-10-89	



- TO J910 SHEET II ZONE B2 TO LAMPSON SWITCHBOARD
- MOTHER BOARD J128 (J55) DIP SW ASSY S125
- 1 →
 - 2 → DIP SW # 1 CALL LIGHT TIME OUT
 - 3 → " " 2 TALK 7-12 ENABLE
 - 4 → " " 3 801 EMULATE
 - 5 → " " 4 ISO EXT-OFF/INT-ON
 - 6 → " " 5 ISO LISTEN ENABLE
 - 7 → " " 6 ISO ENABLE
 - 8 → " " 7 NOT USED
 - 9 → " " 8 IFB TLK DISABLE
 - 10 →
- TO PIO # 2 J402 SHEET 13


5V TO PIO/CPU BOARDS
TO J415 SHEETS 12,13,14
J1 SHEET 15
J153 SHEET 17
J1806 SHEET 18

SEE SHEET 4 ZONE A5 FOR 6 VOLT REGULATOR
USED ON THIS PAGE :
C125 - C138, C140 - C144, D125 - D133, D135 - D137, E25 - E28, F1, F2
Q125 - Q127, R125 - R140, TBI6, U125 - U129

NOT USED :
C139, C140, D133, D134
LAST USED :
C144, D137, E28, F2, Q127, R140, TBI6, U129

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS .XX ± DECIMALS .XXX ± ANGLES °		CONTRACT NO. SERIES 800	RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	SCHEMATIC DIAGRAM, MASTER STATION, MODEL 802, 802A, POWER SUPPLY
FRESH		DRAWN R. NEILSON	1-27-86	
NEXT ASSY	USED ON	CHECKED	ISSUED	SIZE D
APPLICATION		DO NOT SCALE DRAWING		SCALE
		FSCM NO. 60572		DWG. NO. SD 3000
				REV. M
				SHEET 16 OF 26

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED	10-18-82	
	B	UPDATED	10-28-82	
	C	ADDED JUMPER ON W15B	12-9-82	
	D	REV PER ECO # 997	6-14-83	
	E	REV PER ECO #1113	10-11-83	
	F	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES	7-10-86	
	G	REVISED PER ECO # 2391	1-23-89	





FROM DIGITAL ADDRESS BUS TO J4 SHEET 15

FROM DIGITAL DATA OUT BUS TO J2 SHEET 15


FROM DIGITAL POWER BUS TO J127 SHEET 16

1 CHIME OPTION, MODEL 802 ONLY



- 3 U154 IS STANDARD ON THE MODEL 802A. U154 IS USED ON THE 802 ONLY WHEN THE CHIME OPTION IS INSTALLED.
- 2 CABLE SHOWN WITHIN THESE DASHED LINES IS STANDARD ON THE MODEL 802A ONLY (NOT USED ON THE MODEL 802). PI153 PLUGS INTO THE U153 SOCKET (U153 IS NOT USED).
- 1 PARTS SHOWN WITHIN THESE DASHED LINES ARE USED ONLY IN THE MODEL 802 WITH THE CHIME OPTION INSTALLED. THESE PARTS ARE NOT ACTIVE IN THE MODEL 802A. THE CHIME OPTION ON THE 802A IS FOUND ON THE CPU BOARD (SEE SD 5336).





USED ON THIS PAGE: C150-C157, J151-J154, U150-U152, U154, R150-R154, R156, R157



NOTES:

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XXX ± .XXX ± .XXX ±		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
APPROVALS		DATE		SCHEMATIC DIAGRAM, MASTER STATION, MODELS 802 & 802A MOTHER BOARD (CHIME OPTION)	
DRAWN STAN HUBLER		6/30/82		SIZE FSCM NO. DWG. NO.	
CHECKED				D 60572 SD 3000	
ISSUED				SCALE	
NEXT ASSY		USED ON		APPLICATION	
				DO NOT SCALE DRAWING	
				SHEET 17 OF 26	


REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	UPDATED	9-22-82	
	B	UPDATED	9-24-82	
	C	UPDATED	10-28-82	
	D	ADDED R1871A - R1871F	12-17-82	
	E	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1432 FOR COMPLETE LIST OF ADDITIONS / CHANGES	7-10-86	
	F	CHANGED R1813, R1823, R1833, R1843, R1853 & R1863 FROM 33K TO 10K, 1/4W. ECO # 1751 RA	11-17-86	
	G	CHANGED C1815, C1825, C1835, C1845, C1855, C1865 FROM 330pF TO 680pF ECO # 1755	11-24-86	
	H	PER ECO # 2391	2-10-89	



USED ON THIS PAGE: C 1801 - C 1816, C 1821 - C 1826, C 1831 - C 1836, C 1841 - C 1846, C 1851 - C 1856, C 1861 - C 1866, D 1801, DS 1801, U1801 - U1806, U1809, U1807 - U1809, R1811 - R1815, R1821 - R1823, R1831 - R1833, R1841 - R1843, R1851 - R1853, R1861 - R1863, R1870, R1871A - F, R1810A - R1810G, U1807 - U1811

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .001 ± .005		CONTRACT NO. SERIES 800	RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL	APPROVALS	DATE	SCHEMATIC DIAGRAM MODEL 802, 802A MASTER STATION (CALL LIGHT OPTION BOARD)	
FINISH	DRAWN Stan Hubler	CHECKED	SIZE FSCM NO. D 60572	DWG. NO. SD 3000
NEXT ASSY	ISSUED	SCALE NONE	REVISIONS	REVISIONS
USED ON	DO NOT SCALE DRAWING	APPROVED	SCALE NONE	REVISIONS
APPLICATION	DO NOT SCALE DRAWING	APPROVED	SCALE NONE	REVISIONS



REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	UPDATED	10-6-82	
	B	REVISED PER ECO # 832	4-6-83	
	C	REVISED PER ECO # 927	4-27-83	
	D	REVISED PER ECO # 954	5-16-83	
	E	REVISED PER ECO # 997	6-14-83	
	F	REVISED PER ECO # 1113	10-11-83	
	H	REVISED PER ECO # 1428	2-19-85	
	J	REVISED PER ECO # 1581	5-27-86	
	K	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES. ADDED J60 AND MSE	7-10-86	
	L	PER ECO # 2391	2-10-87	



- ④ KI-K6 ARE 12 VOLT, SPDT. OMRON P/N G2E-182P-H-DC12, RTS P/N 1701-0009-00.
3. ALL DIODES ARE IN4004
2. CAPACITANCE VALUES ARE SHOWN MICROFARADS/VOLTS.
1. ALL RESISTORS ARE ± 5%, 1/4 W, CARBON FILM.
- NOTES: UNLESS OTHERWISE SPECIFIED

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XX ± .XXX ±		CONTRACT NO. SERIES 800	RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	SCHEMATIC DIAGRAM, MASTER STATION MODEL 802, 802A RELAYS, RELAY DRIVERS, ANCILLARY CONNECTOR
FINISH		DRAWN S. DUEBBER	7/22/82	
NEXT ASSY	USED ON	ISSUED	SIZE FSCM NO. D 60572	DWG. NO. SD 3000
APPLICATION		DO NOT SCALE DRAWING		SCALE SHEET 19 OF 26

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED	10-11-82	
	B	ADDED E301-E306 DES & NOTE 1 B.MAEZ	11-17-82	
	C	REV. PER ECO #9274924 B.MAEZ	4-26-83	
	D	REV PER ECO #910 B.MAEZ	5-25-83	
	E	ADDED E35, E36, RELATED CUTABLE TRACE & NOTE 2 B.MAEZ	6-23-83	
	F	ADDED GLOBAL RESET TALLY & KEY PINS 6 & 9, J223 GM	10-9-84	
	G	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO #1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES	7-10-86	
	H	PER ECO # 2391	2-10-89	




△ CUT TRACES BETWEEN E33 & E35 AND BETWEEN E34 & E36 FOR AUX PGM. SEE SHT. 6 ZONE A8.

△ THIS CONNECTION USED ONLY WHEN 4-WIRE OPTION IS INSTALLED


UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XXX ±		CONTRACT NO. SERIES 800	RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL	APPROVALS	DATE	SCHEMATIC DIAGRAM, MODEL 802, 802A, MASTER STATION (LINE IN/OUT CONNECTIONS)	
FINISH	DRAWN S. DUEBBER	7/24/82		
NEXT ASSY	USED ON	ISSUED	SIZE D 60572	DWG. NO. SD 3000
APPLICATION	DO NOT SCALE DRAWING	SCALE	REV. H	SHEET 20 OF 26

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED & REDRAWN	10-2-82	
	B	ADDED NOTE 3 & UPDATED	11-23-82	
	C	REVISED PER ECO # 910	5-25-83	
	D	ADDED U601-U603 AND RELATED INFO.	5/13/85	
	E	PER ECO # 2391	2-10-89	



TO J611
LISTEN SWITCHING
PAGE 6

TO J612
LISTEN SWITCHING
PAGE 6




- 1. SEE SHEET 20 FOR HOOKUP OF J105 PINS 13-25, 38-50.
- 2. PAGE 22 IS NOT VALID FOR HUGHES 362470-600
- 3. T601-T606 ARE 10K : 10K TRANSFORMERS. 42TMO18 OR EQUIV.
- 4. ALL RESISTORS ARE 1/4W, 5% CARBON FILM
- NOTES: UNLESS OTHERWISE SPECIFIED

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .002 ± .005		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	SCHEMATIC DIAGRAM	
FINISH		DRAWN	10-2-82	MASTER STATION, MODEL 802, 802A, 4-WIRE OPTION	
NEXT ASSY	USED ON	CHECKED	ISSUED	SIZE FSCM NO. D 60572	DWG. NO. SD 3000
APPLICATION		DO NOT SCALE DRAWING		SCALE	REV. E
					SHEET 22 OF 26

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	REVISED	10-11-82	
	B	REVISED PER ECO# 971	MAEZ 5-11-83	
	C	REVISED PER ECO# 975	MAEZ 5-17-83	
	D	REVISED PER ECO# 1125	MV 11-4-83	
	E	ADDED D04, D07 TO J53 (REF), ADDED KEYS 9 & 10 ON P53	GM 10-9-84	
	F	ADDED INTERSHEET REFERENCES FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES, ADDED J5-8	7-10-86	
	G	PER ECO# 2372	1-3-89	
	H	PER ECO # 2391	1-10-89	

ISO CONNECTOR
J106
50 PIN MALE
(REAR PANEL)





1. ALL DIODES ARE 1AMP,30V SCHOTTKY DIODES;
FOR EXAMPLE: INTERNATIONAL RECTIFIER 11DQ03.
NOTES: UNLESS OTHERWISE SPECIFIED

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES XX ± .XXX ± °		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	SCHEMATIC DIAGRAM, MASTER STATION MODEL 802, 802A, ISO CONNECTOR	
FINISH		DRAWN BMAE2	7-27-82	ISSUED	
NEXT ASSY	USED ON	SCALE		SIZE D	FSCM NO. 60572
APPLICATION		DO NOT SCALE DRAWING		DWG. NO. SD3000	REV. H
				SHEET 23 OF 26	

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
B	REV	REDRAWN PER ECO # 92T		
C	REV	PER ECO # 101G	6-14-83	
D	REVISED	PER ECO 1190	GM 2-23-84	
E	CHANGED	R301 FROM 200Ω TO 390Ω ECO # 1754	RN 11-25-86	

TO 1ST IFB CENTRAL ELECTRONICS UNIT,
MODEL 4010



NOTE 1: 802 UNITS WITH IFB EMULATE OPTIONS 4001 OR 4002 THAT DO NOT HAVE R301 INSTALLED, (UNITS BUILT BEFORE 3-1-84), SHOULD HAVE BILATERAL CURRENT SOURCES 13 AND 14 TERMINATED WITH P102.



NOTE 2: IF MORE THAN ONE 802 WITH IFB EMULATE OPTIONS 4001 OR 4002 IN A SYSTEM HAS BEEN SET TO THE SAME PRIORITY, R301 MUST BE CLIPPED FROM ALL BUT ONE UNIT, THIS WILL PREVENT A LOSS IN SIGNAL GAIN THROUGH DOUBLE TERMINATION.

NOTE 3: SET SLIDE SWITCH S301 TO BILAT 13 POSITION ON IFB OPTION P.C.B.#1; SET S301 TO BILAT 14 POSITION ON IFB OPTION P.C.B.#2.

NOTE 4: THIS DRAWING SHOWS THE IFB CONFIGURATION WHICH EMULATES A MODEL 4002 IFB CONTROL STATION. FOR UNITS WHICH EMULATE A MODEL 4001 IFB CONTROL STATION: a) DISREGARD CIRCUITRY DEALING WITH IFB OPTION P.C.B.#2; b) J1311 OF IFB OPTION P.C.B.#1 CONNECTS TO J161 ON THE MOTHER BD. (SHEETS 8 & 19) INSTEAD OF J311 OF IFB OPTION P.C.B.#2.

NOTES: (UNLESS OTHERWISE SPECIFIED)

TO 2ND IFB CENTRAL ELECTRONICS UNIT
MODEL 4010



NOTE 1: 802 UNITS WITH IFB EMULATE OPTIONS 4001 OR 4002 THAT DO NOT HAVE R301 INSTALLED, (UNITS BUILT BEFORE 3-1-84), SHOULD HAVE BILATERAL CURRENT SOURCES 13 AND 14 TERMINATED WITH P102.

NOTE 2: IF MORE THAN ONE 802 WITH IFB EMULATE OPTIONS 4001 OR 4002 IN A SYSTEM HAS BEEN SET TO THE SAME PRIORITY, R301 MUST BE CLIPPED FROM ALL BUT ONE UNIT, THIS WILL PREVENT A LOSS IN SIGNAL GAIN THROUGH DOUBLE TERMINATION.

NOTE 3: SET SLIDE SWITCH S301 TO BILAT 13 POSITION ON IFB OPTION P.C.B.#1; SET S301 TO BILAT 14 POSITION ON IFB OPTION P.C.B.#2.

NOTE 4: THIS DRAWING SHOWS THE IFB CONFIGURATION WHICH EMULATES A MODEL 4002 IFB CONTROL STATION. FOR UNITS WHICH EMULATE A MODEL 4001 IFB CONTROL STATION: a) DISREGARD CIRCUITRY DEALING WITH IFB OPTION P.C.B.#2; b) J1311 OF IFB OPTION P.C.B.#1 CONNECTS TO J161 ON THE MOTHER BD. (SHEETS 8 & 19) INSTEAD OF J311 OF IFB OPTION P.C.B.#2.

NOTES: (UNLESS OTHERWISE SPECIFIED)

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
FRACTIONS	DECIMALS	ANGLES	APPROVALS	DATE	SCHEMATIC DIAGRAM, MODEL 802, 802A, IFB OPTION
3/16"	.031"	30°	B.MAE	4-27-83	
1/8"	.015"	15°	CHECKED		
1/16"	.0075"	7 1/2°	ISSUED		
MATERIAL			FINISH	SIZE	FRGM. NO.
				D	60572
				SCALE	DWG. NO.
					SD3000
					REV. F
					SHEET 24 OF 26

AS3000-2	802A
NEXT ASSY USED ON	
APPLICATION	

DO NOT SCALE DRAWING

REVISIONS				
ZONE	REV	DESCRIPTION	DATE	APPROVED
	A	REV PER ECO # 927	8, 10, 12	4-27-83
	B	REV PER ECO 1123	12	11-4-83
	C	PER ECO # 2391		2-10-89

BOARD NAME	SUBCATEGORY	ARTWORK DASH #	REFERENCE DESIGNATION #'S	SD 3000 SCHEMATIC SHEET #
MOTHER	MIC. PRE., HEADPHONE & SPEAKER AMPLIFIERS & MISC.	-1	000 TO 124	4, 5
	LISTEN SWITCHING	-1	611 TO 630	6
	TALK, SW BILATERAL CS CH 1-6, CH 13, 14, 15	-1	200 TO 299	8
	POWER SUPPLY	-1	125 TO 149	16
TALK/SQUAWK OPTION	P.C.B. SCHEMATIC	-3	300 TO 399	9
	TALK CONNECTIONS			10
	SQUAWK CONNECTIONS			21
I/O PIO #1 PIO #2 PIO #3	SWITCHBOARD DRIVER	-4	400 TO 499	12
	INTERNAL DRIVER	-4	400 TO 499	13
	EXTERNAL DRIVER	-4	400 TO 499	14
CPU		-5	500 TO 599	15
4W OPTION 1	FOUR WIRE TRANSFORMERS CH 1-6	-6	600 TO 606	22
4W OPTION 2	FOUR WIRE TRANSFORMERS CH 7-12	-6	600 TO 606	22
ADJUSTMENT		-7	700 TO 799	7
SWITCHBOARD		-9	900 TO 999	11
CALL LIGHT OPTION		-18	1800 TO 1899	18
ANALOG BLOCK SCHEMATIC				1, 2
DIGITAL BLOCK SCHEMATIC				3
MOTHER	CHIME OPTION	-1	150 TO 159	17
	INTERCONNECT/RELAYS		160 TO 169	19
	LINE CONNECTOR		170 TO 179	20
	SQUAWK CONNECTOR			21
	FOUR WIRE CONNECTOR			22
	ISO CONNECTOR			23
IFB OPTION		-2		24
	INDEX			25

MODEL 802
REAR PANEL TERMINAL BLOCK CONNECTIONS


- TB 1 - RELAY 1
- TB 2 - RELAY 2
- TB 3 - RELAY 3
- TB 4 - RELAY 4
- TB 5 - RELAY 5
- TB 6 - RELAY 6
- TB 7 - EXT MIC SW
- TB 8 - VCP CONN.
- TB 9 - EXT HDST
- TB 10 - EXT MIC IN
- TB 11 - PGM 1 IN
- TB 12 - PGM 2 IN
- TB 13 - MIC OUTPUT 1
- TB 14 - MIC OUTPUT 2
- TB 15 - EXT SPKR
- TB 16 - POWER INPUT

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .005 ± .005		CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	SCHEMATIC DIAGRAM, MASTER STATION, MODEL 802.802A, INDEX	
FINISH		DRAWN S. DUEBBER	7/27/82	ISSUED	
NEXT ASSY	USED ON	CHECKED		SIZE D	FSCM NO. 60572
APPLICATION		DO NOT SCALE DRAWING		DWG. NO. SD 3000	REV. C
				SCALE	SHEET 25 OF 26

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	ADDED INTERSHEET REFERENCE FOR CLARITY. SEE ECO # 1632 FOR COMPLETE LIST OF ADDITIONS / CHANGES. ADDED J5-8	7-10-86	
	B	PER ECO # 2391	2-10-87	

J103
ISO #2 CONNECTOR
50 PIN MALE
(REAR PANEL)


J106
ISO #1 CONNECTOR
50 PIN MALE
(REAR PANEL)



- ⚠ J310 IS CONNECTED TO 1 OF 4 PRIORITY PLUGS: P51-1, P51-2, P51-3 OR P51-4.
- ⚠ J314 IS CONNECTED TO 1 OF 4 PRIORITY PLUGS: P3314-1, P3314-2, P3314-3 OR P3314-4.
2. THE VCP-12A OPTION HAS BEEN UPDATED FROM THE VCP-12 OPTION TO INCLUDE THE GLOBAL RESET FUNCTION.
1. ALL DIODES ARE 1AMP, 30V SCHOTTKY DIODES, FOR EXAMPLE: INTERNATIONAL RECTIFIER 11DQ03.


NOTES: UNLESS OTHERWISE SPECIFIED.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES, TOLERANCES ARE:		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
FRACTIONS	DECIMALS	APPROVALS	DATE	SCHEMATIC DIAGRAM MASTER STATION, MODEL 802,802A ISO OPTION, VCP-12A	
.XX ±	.XXX ±	R. PEKSON	12-6-84		
FINISH		CHECKED			
DO NOT SCALE DRAWING		ISSUED			
SCALE		SIZE FSCM NO.	DWG. NO.	REV.	
		D 60572	SD3000	B	
		SHEET 26 OF 26			



REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	AA	REDRAWN TO REFLECT CURRENT ASSEMBLY PROCEDURES	5-2-86	
	AB	CHNG TRACES (NEAR C129) TO MATCH AW ECO#16 RB	12/1/86	
	AC	CHNG SHOULDER WASHER CALLOT IN SECT A-A WAS: CONVENE 3054 ECO#1815 RB	3/10/87	
	AD	ADDED RIIB PER ECO 193B	9-30-87	
	AE	REVISED PER ECO # 2372	1-6-89	


SS3000-1 REV
AW3000-1 REV



UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES
TOLERANCES ARE:
FRACTIONS DECIMALS ANGLES
± .XX ±
± .XXX ±

AS 3104		802		MATERIAL		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
NEXT ASSY		USED ON		FINISH		APPROVALS		DATE	
APPLICATION		DO NOT SCALE DRAWING		DRAWN		R.K. Booth		5/2/86	
SIZE		FSCN NO.		DWN. NO.		ISSUED		REV.	
D 60572		AS3000-01		AE		SCALE 1/1		SHEET 1	

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
	A	ADDED PEM NUTS, NOTES 5 & 6, ECO 1695	10-30-86	
	B	CHNG TRACES (NEAR C127) TO MATCH A W REV ELO 1696 RB	12/1/86	
	C	PER ECO # 2372	1-3-89	




SS3000-1 REV J
AW3000-1 REV J

NOTES:


1. PARTS LISTED BELOW ARE SHOWN FILLED IN OR CROSSHATCHED AND ARE NOT INSTALLED AT THIS LEVEL.

CAPACITORS "C"	RESISTORS "R"	IC'S "U"	JUMPERS "W"
142 220 48 42 47	107 106 290 105 58 59 54 108 44A 23 208	154 128 125 126 127 129 150 151 152 153	151 THRU 157 211 221 231 241 251 261 271 281 291
TRANSISTORS "Q"	DIODES "D"		
4	8 9		

- ALL PARTS LISTED IN NOTE 1. AND ALL E HOLES SHOULD BE MASKED OFF PRIOR TO SOLDERWAVE.
- ALL IC'S AND SWITCHES SHOULD HAVE APPROPRIATE DIP SOCKETS.
- APPLY THERMALLOY 251 THERMAL GREASE BETWEEN U9, U10 AND HEATSINK.
- INSTALL PEM NUT KF2-632, RTS P/N 1007-0008-00 (9 PLACES)
- APPLY TORQUE UNTIL COMPRESSION WASHER IS DEPRESSED TO HALF ITS ORIGINAL HEIGHT



AMPHENOL 1-38 758-0 RECEPTACLE (8 REQD)




KF2-440 PEM NUT (2 REQD)

VIEW A-A
SCALE: 2/1

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .005 ± .005		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	ASSY-PCB MOTHERBOARD MODEL 802	
FINISH		DRAWN R.K. BOOTH	2/28/86	REV. C	
AS 3000-01	NEXT ASSY	ISSUED	SIZE FSCM NO. D 60572	DWG. NO. AS 3000-A1	SCALE 1:1 SHEET 1
APPLICATION		DO NOT SCALE DRAWING			


REVISIONS				
ZONE	REV	DESCRIPTION	DATE	APPROVED
	A	REVISED PER ECO # 2222	5-12-88	
	B	REVISED PER ECO # 2359	12-12-88	
	C	REVISED PER ECO # 2391	1-23-89	
	D	REVISED PER ECO # 2406	2-11-89	



▲ U22 IS A PROGRAMMABLE SOUND GENERATOR. U22 IS INSTALLED ONLY IN UNITS WITH THE CHIME OPTION.
 3. THE FOLLOWING ITEMS ARE NOT INSTALLED: U12, U17, U18, W1.
 2. CAPACITANCE VALUES ARE SHOWN: MICROFARADS /VOLTS.
 1. ALL RESISTORS ARE CARBON FILM, 1/4 WATT, ± 5%.
 NOTES: UNLESS OTHERWISE SPECIFIED

<small>UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES .XX .XXX =</small>	CONTRACT NO. SERIES 800		RTS SYSTEMS BURBANK, CALIFORNIA	
	APPROVALS	DATE	SCHEMATIC DIAGRAM, CPU BOARD, MODEL 802, Z-80C VERSION	
	DRAWN R. NELSON	4-16-87	SIZE D	FSCM NO. 60572
	CHECKED		ISSUED	DWG. NO. JD 5336
DO NOT SCALE DRAWING		SCALE	SHEET 1 OF 2	

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED
		SEE SHT 1		




UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XXX ±		CONTRACT NO. SERIES 800	RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL	APPROVALS R. NELSON	DATE 4-16-87	SCHEMATIC DIAGRAM, CPU BOARD, MODEL 802, Z-80C VERSION	
FINISH	CHECKED	ISSUED	SIZE FSCN NO. D 60572	DWG. NO. SD 5336
DO NOT SCALE DRAWING		SCALE	SHEET 2 OF 2	

POWER ON INITIALIZATION

COPYRIGHT 1983 by RTS SYSTEMS, INC. All rights reserved. These plans and/or drawings may not be copied, or transmitted to others, without the written consent of RTS SYSTEMS, INC. 1100 West Chestnut Street, Burbank, CA 91506, U.S.A., which owns all related proprietary rights.


REVISIONS			
ZONE	REV.	DESCRIPTION	DATE



UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .005 ± .005 MATERIAL FINISH	CONTRACT NO. 800 SERIES		RTS SYSTEMS BURBANK, CALIFORNIA	
	APPROVALS	DATE	FLOW CHART, MODEL 802 POWER ON INITIALIZATION	
	DRAWN B,MAE2	5-19-83	SIZE D	PSCM NO. FC3398
	CHECKED	ISSUED	SCALE	DWG. NO. FC3398
NEXT ASSY USED ON APPLICATION		DO NOT SCALE DRAWING		SHEET 1 of 7

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED

MAIN PROGRAM LOOP



ROUTINES EXIST FOR EACH OF THE FOLLOWING BUTTONS:

- ISO
- TALK
- LISTEN
- SQUAWK
- IFB
- IFB ALL
- PRESETS
- UNASSIGNED BUTTONS
- CALL/SETUP
- PANEL MIC
- SPEAKER
- MIC ENABLE

SHEET 3 (points to ISO, TALK, LISTEN)
 SHEET 4 (points to PRESETS, UNASSIGNED BUTTONS)
 SHEETS 5/SHEET 7 (points to CALL/SETUP)
 SHEET 4 (points to PANEL MIC)
 SHEET 3 (points to SPEAKER)
 SHEET 4 (points to MIC ENABLE)

ROUTINES EXIST FOR EACH OF THE FOLLOWING:

- SQUAWK TALLY
- IFB TALLY (EXT IFB)
- EXTERNAL ISO REQUEST OR ISO TALLY (CAM ISO)
- EXTERNAL PRESET-4 REQUEST
- EXTERNAL MIC BUTTON (AUX MIC)
- INCOMING CALLS (CALL PLL)

SHEET 5 (points to the entire list)

Fig -3-10-2-2

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .010 ± .005 ± .001		CONTRACT NO. 800 SERIES		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	FLOW CHART, MODEL 802 MAIN PROGRAM LOOP	
FINISH		DRAWN B. MAEZ	5-19-83	SIZE FSCM NO. DWG. NO. FC3398	
NEXT ASSY USED ON APPLICATION		CHECKED	ISSUED	SCALE 1" = 1" SHEET 2 of 7	
DO NOT SCALE DRAWING					

BUTTON FUNCTIONS .1








Fig = 3-10-2-3

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .001 ± .001 ±		CONTRACT NO. 800 SERIES		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	FLOW CHART, MODEL 802	
FINISH		DRAWN	5-20-83	BUTTON FUNCTIONS 1	
NEXT ASSY USED ON APPLICATION		CHECKED		SIZE	D
		ISSUED		DWG. NO.	FC3398
				SCALE	3 of 7

COPYRIGHT 1983 by RTS SYSTEMS, INC. All rights reserved. These plans and/or drawings may not be copied, or transmitted to others, without the written consent of RTS SYSTEMS, INC., 1100 West Chestnut Street, Burbank, CA 91506, U.S.A., which owns all related proprietary rights.

REVISIONS			
ZONE	REV.	DESCRIPTION	DATE

BUTTON FUNCTIONS 2



7/3-10-2-4

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XX ± ± .XXX ±		CONTRACT NO. 800 SERIES		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	FLOW CHART, MODEL 802 BUTTON FUNCTIONS 2	
FINISH		DRAWN B.MAEZ	5-23-83	CHECKED	
NEXT ASSY USED ON APPLICATION		ISSUED		SCALE	
802		DO NOT SCALE DRAWING		SIZE D	FSCM NO. 40512
				DWG. NO. FC3398	REV.
				SHEET 4 of 7	

EXTERNALS










Fig 3-10-2-5

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .XX ± .XXX ±	CONTRACT NO. 800 SERIES		RTS SYSTEMS BURBANK, CALIFORNIA	
	APPROVALS	DATE	FLOW CHART, MODEL 802 EXTERNALS	
	DRAWN B.MAEZ	5-24-83		
	CHECKED			
ISSUED		SIZE D	FORM NO. 1057L	DWG. NO. FC3398
802		SCALE		REV.
NEXT ASSY USED ON APPLICATION		DO NOT SCALE DRAWING		SHEET 5 of 7

COPYRIGHT 1983 by RTS SYSTEMS, INC. All rights reserved. These plans and/or drawings may not be copied, or transmitted to others, without the written consent of RTS SYSTEMS, INC., 1100 West Chestnut Street, Burbank, CA 91506, U.S.A., which owns all related proprietary rights.

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED

ELECTRONIC SWITCH ACTION




Fig. 3-10-2.6

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .001 ± .001 ±		CONTRACT NO. 800 SERIES		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	FLOW CHART, MODEL 802, ELECTRONIC SWITCH ACTION	
FINISH		DRAWN B.MAEZ	5-24-83	SIZE FROM NO. D 60512 DWG. NO. FC3398	
NEXT ASSY USED ON APPLICATION		CHECKED	ISSUED	SCALE	
802		DO NOT SCALE DRAWING		SHEET 6097	

COPYRIGHT 1983 by RTS SYSTEMS, INC. All rights reserved. These plans and/or drawings may not be copied, or transmitted to others, without the written consent of RTS SYSTEMS, INC., 1100 West Chestnut Street, Burbank, CA 91506, U.S.A., which owns all related proprietary rights.

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED

SETUP MODE




Fig-3-10-2-7

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .001 ± .001		CONTRACT NO. 800 SERIES		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS	DATE	FLOW CHART, MODEL 802, SETUP MODES	
FINISH		DRAWN	5-25-83	CHECKED	
NEXT ASSY USED ON APPLICATION		ISSUED		SIZE	DWG. NO.
				D	FC3398
		DO NOT SCALE DRAWING		SCALE	SHEET 7 of 7

REVISIONS				
NO.	REV.	DESCRIPTION	DATE	APPROVED


TOP ASSEMBLY - MSTR STA. - MODEL 802	AS3104
SCHEMATIC DIAGRAM - 802	SD3000
SCHEMATIC DIAGRAM - STD 802 MSTR STA INTERFACE	SD3002
OUTLINE DRAWING - 802	OD3012
FAB DETAIL, FRONT PANEL	3005
, RIGHT SIDE RAIL	3007
, LEFT SIDE RAIL	3008
, REAR PANEL	3009
, COVER, TOP & BOTTOM	3010
, FRONT PANEL, ADJ BD.	3011
, SUPPORT, CARD GUIDE	3021-2
FAB DETAIL, COVER / SMALL COVER	3163
ASSEMBLY, PCB - MOTHER BD	AS3000-1
SCHEMATIC DIAGRAM	SD3000
MOTHER BD J NUMBERS AND JUMPERS	3096
FAB DETAIL, PCB	3000-1
FAB DETAIL, SUPPORT, ADJ CARD GUIDE	3022
ASSEMBLY, PCB - TALK/SQUAWK/IFB BD	AS3000-3
SCHEMATIC DIAGRAM	SD3000-SHT
FAB DETAIL, PCB	3000-3
ASSEMBLY, PCB - PIO BD #1, 2 & 3	AS3000-4
SCHEMATIC DIAGRAM	SD3000-SHT 12 & 13
FAB DETAIL, PCB	3000-4
ASSEMBLY, PCB - CPU BD	AS3000-5
SCHEMATIC DIAGRAM	SD3000-SHT 15
FAB DETAIL, PCB	3000-5
ASSEMBLY, PCB - 4 WIRE BD	AS3000-6
SCHEMATIC DIAGRAM	SD3000-SHT 22
FAB DETAIL, PCB	3000-6
ASSEMBLY, PCB - ADJUST BD	AS3000-7
SCHEMATIC DIAGRAM	SD3000-SHT 7
FAB DETAIL, PCB	3000-7
FAB DETAIL, SUPPORT, ADJ BD	3023
FAB DETAIL, BRACKET, ADJ CARD STOP	3024
ASSEMBLY, PCB - CALL LIGHT BD	AS3000-18
SCHEMATIC DIAGRAM	SD3000-SHT 18
FAB DETAIL, PCB	3000-18
ASSEMBLY - SUB CHASSIS	AS3006
ASSEMBLY, PCB - SWITCH BD	AS3000-9
SCHEMATIC DIAGRAM	SD3000-SHT 9
FAB DETAIL, PCB	3000-9
FAB DETAIL, SUB CHASSIS	3006
FAB DETAIL, SPEAKER GRILLE	3088

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES FRACTIONS DECIMALS INCHES	CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
	APPROVALS	DATE	DRAWING NUMBER TREE	
MATERIAL	BY: B. MAZ	12-9-82	MSTR STA. - MODEL 802	
FINISH	CHKD:		SIZE: C	PCB NO. DT3176
DO NOT SCALE DRAWING	ISSUED:		DWG. NO. DT3176	REV.
			SCALE: —	INSET: 1 of 1

2 WIRE CHANNELS 1-12 (B3 OPTION, CH 7-12, ADDED)

REVISIONS				
ZONE	REV	DESCRIPTION	DATE	APPROVED

REAR PANEL



FRONT PANEL

2. CHAN 13 ALWAYS OFF.

1. 2 WIRE CHANS 1-6. SWITCHES FOR CHANS 7-12, STILL SET FOR 2 WIRE OPTION, EVEN THOUGH NOT USED WITHOUT B3 OPTION.


NOTES:

<table border="1"> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table>									UNLESS OTHERWISE SPECIFIED REMOVE ALL BURRS & BREAK SHARP EDGES HOLE TOLERANCES PER ANSI B84.1-1987, R1872 DIMENSIONS ARE IN INCHES TOLERANCES ARE FRACTIONS DECIMALS ANGLES ±1/16 ±.005 ±30'	CONTRACT NO. APPROVALS DATE DRAWN NMH CHECKED ISSUED	RTS SYSTEMS BURBANK, CALIFORNIA 802 MOTHER BOARD SWITCHES SIZE B FSCM NO. 60572 DWG. NO. TMI5334 REV. SCALE SHEET 1 OF 6
MATERIAL FINISH	DO NOT SCALE DRAWING	APPLICATION	NEXTassy USED ON								

4 WIRE CHANNELS 1-12 (C2 & C3 WITH B3, TALK 7-12, ADDED)

REVISIONS				
ZONE	REV	DESCRIPTION	DATE	APPROVED

REAR PANEL



FRONT PANEL


1. CHAN 13 ALWAYS OFF.
NOTES:

UNLESS OTHERWISE SPECIFIED REMOVE ALL BURRS & BREAK SHARP EDGES HOLE TOLERANCES PER ANSI B91.1-1987, R1973 DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES .1/16 .005 .030 .001 .002 .010		CONTRACT NO.	
		APPROVALS DATE DRAWN NMH CHECKED ISSUED	
MATERIAL		RTSS SYSTEMS BURBANK, CALIFORNIA 802 MOTHER BOARD SWITCHES	
NEXT ASSY USED ON		SIZE FSCM NO.	DWG. NO.
APPLICATION		B 60572	TMI5334
FINISH		SCALE	REV.
		DO NOT SCALE DRAWING	SHEET 2 OF 6

2 WIRE CHANNELS 1-6
 4 WIRE CHANNELS 7-12 (C3 w/B3, TALK 7-12, ADDED)

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED

REAR PANEL



FRONT PANEL


1. CHAN 13 ALWAYS OFF,
 NOTES:

<table border="1"> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table>									UNLESS OTHERWISE SPECIFIED REMOVE ALL BURRS & BREAK SHARP EDGES HOLE TOLERANCES PER ANSI #4-11-1987, #1-1973 DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS 1/16 DECIMAL .001 ANGLES .030 .001 .002 .005 .010	CONTRACT NO. APPROVALS DATE DRAWN CHECKED ISSUED	RTS SYSTEMS BURBANK, CALIFORNIA 802 MOTHER BOARD SWITCHES SIZE B FSCM NO. 60572 DWG. NO. TMI5334 REV. SCALE — SHEET 3 OF 6
MATERIAL FINISH	APPLICATION	DO NOT SCALE DRAWING	SHEET 3 OF 6								

4 WIRE CHANNELS 1-6(C2)
2 WIRE CHANNELS 7-12(B3)

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED

REAR PANEL



FRONT PANEL


1. CHAN 13 ALWAYS OFF.
NOTES:

<table border="1"> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table>									<p>UNLESS OTHERWISE SPECIFIED</p> <p>REMOVE ALL BURRS & BREAK SHARP EDGES</p> <p>HOLE TOLERANCES PER ANSI B91.1-1987, A1 B12</p> <p>DIMENSIONS ARE IN INCHES</p> <p>TOLERANCES ARE:</p> <table border="1"> <tr> <td>FRACTIONS</td> <td>DECIMALS</td> <td>ANGLES</td> </tr> <tr> <td>± 1/16</td> <td>± 0.015</td> <td>± 30'</td> </tr> <tr> <td>± 1/32</td> <td>± 0.005</td> <td>± 30'</td> </tr> </table>	FRACTIONS	DECIMALS	ANGLES	± 1/16	± 0.015	± 30'	± 1/32	± 0.005	± 30'	<p>CONTRACT NO.</p> <p>APPROVALS</p> <p>DATE</p> <p>DRAWN</p> <p>CHECKED</p> <p>ISSUED</p>	<p>RTS SYSTEMS BURBANK, CALIFORNIA</p> <p>802 MOTHER BOARD SWITCHES</p> <p>SIZE FSCM NO. B 60572 DWG. NO. TMI5334 REV.</p>
FRACTIONS	DECIMALS	ANGLES																		
± 1/16	± 0.015	± 30'																		
± 1/32	± 0.005	± 30'																		
<p>MATERIAL</p> <p>FINISH</p>	<p>DO NOT SCALE DRAWING</p>	<p>SCALE</p>	<p>SHEET 4 OF 6</p>																	
<p>APPLICATION</p>	<p> </p>	<p> </p>	<p> </p>																	
<p> </p>	<p> </p>	<p> </p>	<p> </p>																	

MIXED 2 WIRE & 4 WIRE CHANNELS 1-12 (B3, CHANS 7-12, ADDED)

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED

REAR PANEL



FRONT PANEL

SHOWN:
 2 WIRE 4 WIRE
 CH1,3,5, CH2,4
 6,8,10,11 7,9,12
 14,15


1. CHAN 13 ALWAYS OFF
 NOTES:

<table border="1"> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </table>									UNLESS OTHERWISE SPECIFIED REMOVE ALL SURF BREAKS/SHARP EDGES HOLE TOLERANCES PER ANSI B94.11-1987 #10/75 DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS 2 ±.02 1/16 .002 DECIMALS .002 ANGLES .30°	CONTRACT NO. _____ APPROVALS _____ DATE _____ DRAWN _____ CHECKED _____ ISSUED _____ DO NOT SCALE DRAWING	RTS SYSTEMS BURLINGAME, CALIFORNIA 802 MOTHER BOARD SWITCHES SIZE B FSCM NO. 60572 DWG. NO. TMI5334 REV. _____ SCALE _____ SHEET 5 OF 6
MATERIAL _____ FINISH _____ APPLICATION _____	NEXT ASSY _____ USED ON _____	_____	_____								

2 WIRE/4 WIRE SIMULTANEOUS OPERATION CHANNELS
 1-12 (B3, CHANNELS 7-12, ADDED).

REVISIONS				
ZONE	REV.	DESCRIPTION	DATE	APPROVED

REAR PANEL



FRONT PANEL

2, CHAN 13 ALWAYS OFF.
 1, ALL RESISTORS ARE 10K, 1/8W.
 NOTES:

UNLESS OTHERWISE SPECIFIED REMOVE ALL BURRS & BREAK SHARP EDGES HOLE TOLERANCES PER ANSI B94.11-1967, B1.873 DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS ±.010 DECIMALS ±.005 ANGLES ±30'		CONTRACT NO.		RTS SYSTEMS BURBANK, CALIFORNIA	
MATERIAL		APPROVALS			
FINISH		DRAWN		NWH	
NEXT ASSY		CHECKED		ISSUED	
APPLICATION		DO NOT SCALE DRAWING		SCALE	
		SIZE		FSCM NO.	
		B		60572	
		DWG. NO.		REV.	
		TM15334			
		SHEET		6 OF 6	